

Merk Handset	Type Handset	Keyword (1)	Keyword (2)
AIKO	51G	GPRS/MMS/3G AIKO 51G	GPRS/MMS/3G AIKO 51-G
AIKO	52G	GPRS/MMS/3G AIKO 52G	GPRS/MMS/3G AIKO 52-G
AIKO	78G	GPRS/MMS/3G AIKO 78G	GPRS/MMS/3G AIKO 78-G
AIKO	95G	GPRS/MMS/3G AIKO 95G	GPRS/MMS/3G AIKO 95-G
AIKO	97G	GPRS/MMS/3G AIKO 97G	GPRS/MMS/3G AIKO 97-G
Alcatel	ELLE NO 3	GPRS/MMS/3G Alcatel ELLENO3	GPRS/MMS/3G Alcatel ELLE-NO3
Alcatel	One Touch 155	GPRS/MMS/3G Alcatel OneTouch155	GPRS/MMS/3G Alcatel OneTouch-155
Alcatel	One Touch 155a	GPRS/MMS/3G Alcatel OneTouch155a	GPRS/MMS/3G Alcatel OneTouch-155a
Alcatel	One Touch 156	GPRS/MMS/3G Alcatel OneTouch156	GPRS/MMS/3G Alcatel OneTouch-156
Alcatel	One Touch 156a	GPRS/MMS/3G Alcatel OneTouch156a	GPRS/MMS/3G Alcatel OneTouch-156a
Alcatel	One Touch 301	GPRS/MMS/3G Alcatel OneTouch301	GPRS/MMS/3G Alcatel OneTouch-301
Alcatel	One Touch 302	GPRS/MMS/3G Alcatel OneTouch302	GPRS/MMS/3G Alcatel OneTouch-302
Alcatel	One Touch 303	GPRS/MMS/3G Alcatel OneTouch303	GPRS/MMS/3G Alcatel OneTouch-303
Alcatel	One Touch 311	GPRS/MMS/3G Alcatel OneTouch311	GPRS/MMS/3G Alcatel OneTouch-311
Alcatel	One Touch 331	GPRS/MMS/3G AlcatelOneTouch331	GPRS/MMS/3G Alcatel OneTouch-331
Alcatel	One Touch 331a	GPRS/MMS/3G Alcatel OneTouch331a	GPRS/MMS/3G Alcatel OneTouch-331a
Alcatel	One Touch 331P	GPRS/MMS/3G Alcatel OneTouch331P	GPRS/MMS/3G Alcatel OneTouch-331P
Alcatel	One Touch 332	GPRS/MMS/3G Alcatel OneTouch332	GPRS/MMS/3G Alcatel OneTouch-332
Alcatel	One Touch 332a	GPRS/MMS/3G Alcatel OneTouch332a	GPRS/MMS/3G Alcatel OneTouch-332a
Alcatel	One Touch 333	GPRS/MMS/3G Alcatel OneTouch333	GPRS/MMS/3G Alcatel OneTouch-333
Alcatel	One Touch 355	GPRS/MMS/3G Alcatel OneTouch355	GPRS/MMS/3G Alcatel OneTouch-355
Alcatel	One Touch 355a	GPRS/MMS/3G Alcatel OneTouch355a	GPRS/MMS/3G Alcatel OneTouch-355a
Alcatel	One Touch 501	GPRS/MMS/3G Alcatel OneTouch501	GPRS/MMS/3G Alcatel OneTouch-501
Alcatel	One Touch 511	GPRS/MMS/3G Alcatel OneTouch511	GPRS/MMS/3G Alcatel OneTouch-511
Alcatel	One Touch 512	GPRS/MMS/3G Alcatel OneTouch512	GPRS/MMS/3G Alcatel OneTouch-512
Alcatel	One Touch 525	GPRS/MMS/3G Alcatel OneTouch525	GPRS/MMS/3G Alcatel OneTouch-525
Alcatel	One Touch 526	GPRS/MMS/3G Alcatel OneTouch526	GPRS/MMS/3G Alcatel OneTouch-526
Alcatel	One Touch 531	GPRS/MMS/3G Alcatel OneTouch531	GPRS/MMS/3G Alcatel OneTouch-531
Alcatel	One Touch 535	GPRS/MMS/3G Alcatel OneTouch535	GPRS/MMS/3G Alcatel OneTouch-535
Alcatel	One Touch 556	GPRS/MMS/3G Alcatel OneTouch556	GPRS/MMS/3G Alcatel OneTouch-556
Alcatel	One Touch 557	GPRS/MMS/3G Alcatel OneTouch557	GPRS/MMS/3G Alcatel OneTouch-557
Alcatel	One Touch 557a	GPRS/MMS/3G Alcatel OneTouch557a	GPRS/MMS/3G Alcatel OneTouch-557a
Alcatel	One Touch 565	GPRS/MMS/3G Alcatel OneTouch565	GPRS/MMS/3G Alcatel OneTouch-565
Alcatel	One Touch 701	GPRS/MMS/3G Alcatel OneTouch701	GPRS/MMS/3G Alcatel OneTouch-701
Alcatel	One Touch 715	GPRS/MMS/3G Alcatel OneTouch715	GPRS/MMS/3G Alcatel OneTouch-715
Alcatel	One Touch 735	GPRS/MMS/3G Alcatel OneTouch735	GPRS/MMS/3G Alcatel OneTouch-735
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouch735i	GPRS/MMS/3G Alcatel OneTouch-735i
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouch756	GPRS/MMS/3G Alcatel OneTouch-756
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouch757	GPRS/MMS/3G Alcatel OneTouch-757
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouch835	GPRS/MMS/3G Alcatel OneTouch-835
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC550	GPRS/MMS/3G Alcatel OneTouch-C550
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC550a	GPRS/MMS/3G Alcatel OneTouch-C550a
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC551	GPRS/MMS/3G Alcatel OneTouch-C551
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC551a	GPRS/MMS/3G Alcatel OneTouch-C551a
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC552	GPRS/MMS/3G Alcatel OneTouch-C552
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC555	GPRS/MMS/3G Alcatel OneTouch-C555
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OnetouchC560	GPRS/MMS/3G Alcatel OneTouch-C560
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC560a	GPRS/MMS/3G Alcatel OneTouch-C560a
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC630	GPRS/MMS/3G Alcatel OneTouch-C630
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC635	GPRS/MMS/3G Alcatel OneTouch-C635
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC635a	GPRS/MMS/3G Alcatel OneTouch-C635a
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC651	GPRS/MMS/3G Alcatel OneTouch-C651
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC652	GPRS/MMS/3G Alcatel OneTouch-C652
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC652a	GPRS/MMS/3G Alcatel OneTouch-C652a

Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC656	GPRS/MMS/3G Alcatel OneTouch-C656
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC701	GPRS/MMS/3G Alcatel OneTouch-C701
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC701a	GPRS/MMS/3G Alcatel OneTouch-C701a
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC707	GPRS/MMS/3G Alcatel OneTouch-C707
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC717	GPRS/MMS/3G Alcatel OneTouch-C717
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC750	GPRS/MMS/3G Alcatel OneTouch-C750
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC750a	GPRS/MMS/3G Alcatel OneTouch-C750a
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC753	GPRS/MMS/3G Alcatel OneTouch-C753
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC820a	GPRS/MMS/3G Alcatel OneTouch-C820a
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchC825	GPRS/MMS/3G Alcatel OneTouch-C825
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchS850	GPRS/MMS/3G Alcatel OneTouch-S850
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchS8	GPRS/MMS/3G Alcatel OneTouch-S853
Alcatel	One Touch 735i	GPRS/MMS/3G Alcatel OneTouchS853a	GPRS/MMS/3G Alcatel OneTouch-S853a
Audiovox	One Touch 735i	GPRS/MMS/3G Audiovox GPRS900	GPRS/MMS/3G Audiovox GPRS-900
BenQ	One Touch 735i	GPRS/MMS/3G BenQ A500	GPRS/MMS/3G BenQ A-500
BenQ	One Touch 735i	GPRS/MMS/3G BenQ A520	GPRS/MMS/3G BenQ A-520
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M100	GPRS/MMS/3G BenQ M-100
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M220	GPRS/MMS/3G BenQ M-220
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M300	GPRS/MMS/3G BenQ M-300
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M305	GPRS/MMS/3G BenQ M-305
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M315	GPRS/MMS/3G BenQ M-315
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M350	GPRS/MMS/3G BenQ M-350
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M580	GPRS/MMS/3G BenQ M-580
BenQ	One Touch 735i	GPRS/MMS/3G BenQ M580a	GPRS/MMS/3G BenQ M-580a
BenQ	One Touch 735i	GPRS/MMS/3G BenQ P30	GPRS/MMS/3G BenQ P-30
BenQ	One Touch 735i	GPRS/MMS/3G BenQ P31	GPRS/MMS/3G BenQ P-31
BenQ	One Touch 735i	GPRS/MMS/3G BenQ S500	GPRS/MMS/3G BenQ S-500
BenQ	One Touch 735i	GPRS/MMS/3G BenQ S660	GPRS/MMS/3G BenQ S-660
BenQ	One Touch 735i	GPRS/MMS/3G BenQ S660C	GPRS/MMS/3G BenQ S-660C
BenQ	One Touch 735i	GPRS/MMS/3G BenQ S670C	GPRS/MMS/3G BenQ S-670C
BenQ	One Touch 735i	GPRS/MMS/3G BenQ S700	GPRS/MMS/3G BenQ S-700
BenQ	One Touch 735i	GPRS/MMS/3G BenQ S80	GPRS/MMS/3G BenQ S-80
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens A58	GPRS/MMS/3G BenQ-Siemens A- 58
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens C81	GPRS/MMS/3G BenQ-Siemens C-81
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens CF51	GPRS/MMS/3G BenQ-Siemens CF-51
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens CF61	GPRS/MMS/3G BenQ-Siemens CF-61
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens CL71	GPRS/MMS/3G BenQ-Siemens CL-71
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens E61	GPRS/MMS/3G BenQ-Siemens E-61
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens E71	GPRS/MMS/3G BenQ-Siemens E-71
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens E81	GPRS/MMS/3G BenQ-Siemens E-81
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens EF61	GPRS/MMS/3G BenQ-Siemens EF-61
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens EF71	GPRS/MMS/3G BenQ-Siemens EF-71
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens EF81	GPRS/MMS/3G BenQ-Siemens EF-81
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens EF91	GPRS/MMS/3G BenQ-Siemens EF-91
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens M81	GPRS/MMS/3G BenQ-Siemens M81
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens S68	GPRS/MMS/3G BenQ-Siemens S68
BenQ-Siemens	One Touch 735i	GPRS/MMS/3G BenQ-Siemens S81	GPRS/MMS/3G BenQ-Siemens S81
BenQ	One Touch 735i	GPRS/MMS/3G BenQ Z2	GPRS/MMS/3G BenQ Z2
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson A2628s	GPRS/MMS/3G Ericsson A-2628s
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson A2628sc	GPRS/MMS/3G Ericsson A-2628sc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson A2638s	GPRS/MMS/3G Ericsson A-2638s
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson A2638sc	GPRS/MMS/3G Ericsson A-2638sc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R320s	GPRS/MMS/3G Ericsson R-320s
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R320sc	GPRS/MMS/3G Ericsson R-320sc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R320TITAN	GPRS/MMS/3G Ericsson R320-TITAN

Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R380s	GPRS/MMS/3G Ericsson R-380s
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R380sc	GPRS/MMS/3G Ericsson R-380sc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R380 world	GPRS/MMS/3G Ericsson R380-world
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R520m	GPRS/MMS/3G Ericsson R-520m
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R520mc	GPRS/MMS/3G Ericsson R-520mc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson R600	GPRS/MMS/3G Ericsson R-600
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T20e	GPRS/MMS/3G Ericsson T-20e
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T20ec	GPRS/MMS/3G Ericsson T-20ec
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T20s	GPRS/MMS/3G Ericsson T-20s
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T20sc	GPRS/MMS/3G Ericsson t-20sc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T29	GPRS/MMS/3G Ericsson T-29
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T29s	GPRS/MMS/3G Ericsson T-29s
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T29sc	GPRS/MMS/3G Ericsson T-29sc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T39m	GPRS/MMS/3G Ericsson T-39m
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T39mc	GPRS/MMS/3G Ericsson T-39mc
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T65s	GPRS/MMS/3G Ericsson T-65s
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T66	GPRS/MMS/3G Ericsson T-66
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T68	GPRS/MMS/3G Ericsson T-68
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T68i	GPRS/MMS/3G Ericsson T-68i
Ericsson	One Touch 735i	GPRS/MMS/3G Ericsson T68mc	GPRS/MMS/3G Ericsson T-68mc
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GC-300	GPRS/MMS/3G Gradiente GC300
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GC-370	GPRS/MMS/3G Gradiente GC370
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-500	GPRS/MMS/3G Gradiente GF500
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-690	GPRS/MMS/3G Gradiente GF690
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-690v	GPRS/MMS/3G Gradiente GF690v
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-760	GPRS/MMS/3G Gradiente GF760
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-910	GPRS/MMS/3G Gradiente GF910
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-910i	GPRS/MMS/3G Gradiente GF910i
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-930	GPRS/MMS/3G Gradiente GF930
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-930i	GPRS/MMS/3G Gradiente GF930i
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-950	GPRS/MMS/3G Gradiente GF950
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente GF-970	GPRS/MMS/3G Gradiente GF970
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente NeoCamGX-5II	GPRS/MMS/3G Gradiente NeoCam-GX-5II
Gradiente	One Touch 735i	GPRS/MMS/3G Gradiente ViBE	
Haier	One Touch 735i	GPRS/MMS/3G Haier HG-E30	GPRS/MMS/3G Haier HGE30
HTC	One Touch 735i	GPRS/MMS/3G HTC Tanager	
i-mate	One Touch 735i	GPRS/MMS/3G i-mate Smartphone	GPRS/MMS/3G imate Smartphone
LG	One Touch 735i	GPRS/MMS/3G LG A7110	GPRS/MMS/3G LG A-7110
LG	One Touch 735i	GPRS/MMS/3G LG A7150	GPRS/MMS/3G LG A-7150
LG	One Touch 735i	GPRS/MMS/3G LG B1300	GPRS/MMS/3G LG B-1300
LG	One Touch 735i	GPRS/MMS/3G LG B2000	GPRS/MMS/3G LG B-2000
LG	One Touch 735i	GPRS/MMS/3G LG B2050	GPRS/MMS/3G LG B-2050
LG	One Touch 735i	GPRS/MMS/3G LG B2070	GPRS/MMS/3G LG B-2070
LG	One Touch 735i	GPRS/MMS/3G LG B2100	GPRS/MMS/3G LG B-2100
LG	One Touch 735i	GPRS/MMS/3G LG B2150	GPRS/MMS/3G LG B-2150
LG	One Touch 735i	GPRS/MMS/3G LG B2250	GPRS/MMS/3G LG B-2250
LG	One Touch 735i	GPRS/MMS/3G LG C1100	GPRS/MMS/3G LG C-1100
LG	One Touch 735i	GPRS/MMS/3G LG C1150	GPRS/MMS/3G LG C-1150
LG	One Touch 735i	GPRS/MMS/3G LG C1200	GPRS/MMS/3G LG C-1200
LG	One Touch 735i	GPRS/MMS/3G LG C1300	GPRS/MMS/3G LG C-1300
LG	One Touch 735i	GPRS/MMS/3G LG C1300i	GPRS/MMS/3G LG C-1300i
LG	One Touch 735i	GPRS/MMS/3G LG C1400	GPRS/MMS/3G LG C-1400
LG	One Touch 735i	GPRS/MMS/3G LG C1500	GPRS/MMS/3G LG C-1500
LG	One Touch 735i	GPRS/MMS/3G LG C2000	GPRS/MMS/3G LG C-2000
LG	One Touch 735i	GPRS/MMS/3G LG C2100	GPRS/MMS/3G LG C-2100

LG	One Touch 735i	GPRS/MMS/3G LG C2200	GPRS/MMS/3G LG C-2200
LG	One Touch 735i	GPRS/MMS/3G LG C2500	GPRS/MMS/3G LG C-2500
LG	One Touch 735i	GPRS/MMS/3G LG C3100	GPRS/MMS/3G LG C-3100
LG	One Touch 735i	GPRS/MMS/3G LG C3300	GPRS/MMS/3G LG C-3300
LG	One Touch 735i	GPRS/MMS/3G LG C3310	GPRS/MMS/3G LG C-3310
LG	One Touch 735i	GPRS/MMS/3G LG C3320	GPRS/MMS/3G LG C-3320
LG	One Touch 735i	GPRS/MMS/3G LG C3380	GPRS/MMS/3G LG C-3380
LG	One Touch 735i	GPRS/MMS/3G LG C3400	GPRS/MMS/3G LG C-3400
LG	One Touch 735i	GPRS/MMS/3G LG C3600	GPRS/MMS/3G LG C-3600
LG	One Touch 735i	GPRS/MMS/3G LG C4300	GPRS/MMS/3G LG C-4300
LG	One Touch 735i	GPRS/MMS/3G LG CE110	GPRS/MMS/3G LG CE-110
LG	One Touch 735i	GPRS/MMS/3G LG CE500	GPRS/MMS/3G LG CE-500
LG	One Touch 735i	GPRS/MMS/3G LG CG180	GPRS/MMS/3G LG CG-180
LG	One Touch 735i	GPRS/MMS/3G LG CG225	GPRS/MMS/3G LG CG-225
LG	One Touch 735i	GPRS/MMS/3G LG CG300	GPRS/MMS/3G LG CG-300
LG	One Touch 735i	GPRS/MMS/3G LG CU320	GPRS/MMS/3G LG CU-320
LG	One Touch 735i	GPRS/MMS/3G LG CU400	GPRS/MMS/3G LG CU-400
LG	One Touch 735i	GPRS/MMS/3G LG CU405	GPRS/MMS/3G LG CU-405
LG	One Touch 735i	GPRS/MMS/3G LG CU500	GPRS/MMS/3G LG CU-500
LG	One Touch 735i	GPRS/MMS/3G LG CU500v	GPRS/MMS/3G LG CU-500v
LG	One Touch 735i	GPRS/MMS/3G LG F1200	GPRS/MMS/3G LG F-1200
LG	One Touch 735i	GPRS/MMS/3G LG F2100	GPRS/MMS/3G LG F-2100
LG	One Touch 735i	GPRS/MMS/3G LG F2200	GPRS/MMS/3G LG F-2200
LG	One Touch 735i	GPRS/MMS/3G LG F2250	GPRS/MMS/3G LG F-2250
LG	One Touch 735i	GPRS/MMS/3G LG F2300	GPRS/MMS/3G LG F-2300
LG	One Touch 735i	GPRS/MMS/3G LG F2400	GPRS/MMS/3G LG F-2400
LG	One Touch 735i	GPRS/MMS/3G LG F2410	GPRS/MMS/3G LG F-2410
LG	One Touch 735i	GPRS/MMS/3G LG F2500	GPRS/MMS/3G LG F-2500
LG	One Touch 735i	GPRS/MMS/3G LG F3000	GPRS/MMS/3G LG F-3000
LG	One Touch 735i	GPRS/MMS/3G LG F7100	GPRS/MMS/3G LG F-7100
LG	One Touch 735i	GPRS/MMS/3G LG F7200	GPRS/MMS/3G LG F-7200
LG	One Touch 735i	GPRS/MMS/3G LG F7250	GPRS/MMS/3G LG F-7250
LG	One Touch 735i	GPRS/MMS/3G LG F9100	GPRS/MMS/3G LG F-9100
LG	One Touch 735i	GPRS/MMS/3G LG F9200	GPRS/MMS/3G LG F-3200
LG	One Touch 735i	GPRS/MMS/3G LG G1500	GPRS/MMS/3G LG G-1500
LG	One Touch 735i	GPRS/MMS/3G LG G1600	GPRS/MMS/3G LG G-1600
LG	One Touch 735i	GPRS/MMS/3G LG G1610	GPRS/MMS/3G LG G-1610
LG	One Touch 735i	GPRS/MMS/3G LG G1700	GPRS/MMS/3G LG G-1700
LG	One Touch 735i	GPRS/MMS/3G LG G1800	GPRS/MMS/3G LG G-1800
LG	One Touch 735i	GPRS/MMS/3G LG G210	GPRS/MMS/3G LG G-210
LG	One Touch 735i	GPRS/MMS/3G LG G220	GPRS/MMS/3G LG G-220
LG	One Touch 735i	GPRS/MMS/3G LG G262	GPRS/MMS/3G LG G-262
LG	One Touch 735i	GPRS/MMS/3G LG G282	GPRS/MMS/3G LG G-282
LG	One Touch 735i	GPRS/MMS/3G LG G3000	GPRS/MMS/3G LG G-3000
LG	One Touch 735i	GPRS/MMS/3G LG G3100	GPRS/MMS/3G LG G-3100
LG	One Touch 735i	GPRS/MMS/3G LG G4010	GPRS/MMS/3G LG G-4010
LG	One Touch 735i	GPRS/MMS/3G LG G4011	GPRS/MMS/3G LG G-4011
LG	One Touch 735i	GPRS/MMS/3G LG G4015	GPRS/MMS/3G LG G-4015
LG	One Touch 735i	GPRS/MMS/3G LG G4020	GPRS/MMS/3G LG G-4020
LG	One Touch 735i	GPRS/MMS/3G LG G4050	GPRS/MMS/3G LG G-4050
LG	One Touch 735i	GPRS/MMS/3G LG G510	GPRS/MMS/3G LG G-510
LG	One Touch 735i	GPRS/MMS/3G LG G5200	GPRS/MMS/3G LG G-5200
LG	One Touch 735i	GPRS/MMS/3G LG G5210	GPRS/MMS/3G LG G-5210
LG	One Touch 735i	GPRS/MMS/3G LG G5220	GPRS/MMS/3G LG G-5220
LG	One Touch 735i	GPRS/MMS/3G LG G5220C	GPRS/MMS/3G LG G-5220c

LG	One Touch 735i	GPRS/MMS/3G LG G5300	GPRS/MMS/3G LG G-5300
LG	One Touch 735i	GPRS/MMS/3G LG G5300i	GPRS/MMS/3G LG G-5300i
LG	One Touch 735i	GPRS/MMS/3G LG G5310	GPRS/MMS/3G LG G-5310
LG	One Touch 735i	GPRS/MMS/3G LG G5400	GPRS/MMS/3G LG G-5400
LG	One Touch 735i	GPRS/MMS/3G LG G5410	GPRS/MMS/3G LG G-5410
LG	One Touch 735i	GPRS/MMS/3G LG G5500	GPRS/MMS/3G LG G-5500
LG	One Touch 735i	GPRS/MMS/3G LG G5600	GPRS/MMS/3G LG G-5600
LG	One Touch 735i	GPRS/MMS/3G LG G610	GPRS/MMS/3G LG G-610
LG	One Touch 735i	GPRS/MMS/3G LG G622	GPRS/MMS/3G LG G-622
LG	One Touch 735i	GPRS/MMS/3G LG G650	GPRS/MMS/3G LG G-650
LG	One Touch 735i	GPRS/MMS/3G LG G672	GPRS/MMS/3G LG G-672
LG	One Touch 735i	GPRS/MMS/3G LG G7000	GPRS/MMS/3G LG G-7000
LG	One Touch 735i	GPRS/MMS/3G LG G7000A	GPRS/MMS/3G LG G-7000A
LG	One Touch 735i	GPRS/MMS/3G LG G7010	GPRS/MMS/3G LG G-7010
LG	One Touch 735i	GPRS/MMS/3G LG G7020	GPRS/MMS/3G LG G-7020
LG	One Touch 735i	GPRS/MMS/3G LG G7030	GPRS/MMS/3G LG G-7030
LG	One Touch 735i	GPRS/MMS/3G LG G7050	GPRS/MMS/3G LG G-7050
LG	One Touch 735i	GPRS/MMS/3G LG G7070	GPRS/MMS/3G LG G-7070
LG	One Touch 735i	GPRS/MMS/3G LG G7100	GPRS/MMS/3G LG G-7100
LG	One Touch 735i	GPRS/MMS/3G LG G7110	GPRS/MMS/3G LG G-7110
LG	One Touch 735i	GPRS/MMS/3G LG G7120	GPRS/MMS/3G LG G-7120
LG	One Touch 735i	GPRS/MMS/3G LG G7200	GPRS/MMS/3G LG G-7200
LG	One Touch 735i	GPRS/MMS/3G LG G8000	GPRS/MMS/3G LG G-8000
LG	One Touch 735i	GPRS/MMS/3G LG G912	GPRS/MMS/3G LG G-912
LG	One Touch 735i	GPRS/MMS/3G LG KE260	GPRS/MMS/3G LG KE-260
LG	One Touch 735i	GPRS/MMS/3G LG KE500	GPRS/MMS/3G LG KE-500
LG	One Touch 735i	GPRS/MMS/3G LG KE600	GPRS/MMS/3G LG KE-600
LG	One Touch 735i	GPRS/MMS/3G LG KE770Shine	GPRS/MMS/3G LG KE770-Shine
LG	One Touch 735i	GPRS/MMS/3G LG KE800	GPRS/MMS/3G LG KE-800
LG	One Touch 735i	GPRS/MMS/3G LG KE820	GPRS/MMS/3G LG KE-820
LG	One Touch 735i	GPRS/MMS/3G LG KE850Prada	GPRS/MMS/3G LG KE850-Prada
LG	One Touch 735i	GPRS/MMS/3G LG KE970Shine	GPRS/MMS/3G LG KE970-Shine
LG	One Touch 735i	GPRS/MMS/3G LG KG110	GPRS/MMS/3G LG KG-110
LG	One Touch 735i	GPRS/MMS/3G LG KG120	GPRS/MMS/3G LG KG-120
LG	One Touch 735i	GPRS/MMS/3G LG KG130	GPRS/MMS/3G LG KG-130
LG	One Touch 735i	GPRS/MMS/3G LG KG190	GPRS/MMS/3G LG KG-190
LG	One Touch 735i	GPRS/MMS/3G LG KG200	GPRS/MMS/3G LG KG-200
LG	One Touch 735i	GPRS/MMS/3G LG KG210	GPRS/MMS/3G LG KG-210
LG	One Touch 735i	GPRS/MMS/3G LG KG220	GPRS/MMS/3G LG KG-220
LG	One Touch 735i	GPRS/MMS/3G LG KG225	GPRS/MMS/3G LG KG-225
LG	One Touch 735i	GPRS/MMS/3G LG KG238	GPRS/MMS/3G LG KG-238
LG	One Touch 735i	GPRS/MMS/3G LG KG240	GPRS/MMS/3G LG KG-240
LG	One Touch 735i	GPRS/MMS/3G LG KG245	GPRS/MMS/3G LG KG-245
LG	One Touch 735i	GPRS/MMS/3G LG KG280	GPRS/MMS/3G LG KG-280
LG	One Touch 735i	GPRS/MMS/3G LG KG290	GPRS/MMS/3G LG KG-290
LG	One Touch 735i	GPRS/MMS/3G LG KG296	GPRS/MMS/3G LG KG-296
LG	One Touch 735i	GPRS/MMS/3G LG KG300	GPRS/MMS/3G LG KG-300
LG	One Touch 735i	GPRS/MMS/3G LG KG320	GPRS/MMS/3G LG KG-320
LG	One Touch 735i	GPRS/MMS/3G LG KG330	GPRS/MMS/3G LG KG-330
LG	One Touch 735i	GPRS/MMS/3G LG KG70Shine	GPRS/MMS/3G LG KG70-Shine
LG	One Touch 735i	GPRS/MMS/3G LG KG800Chocolate	GPRS/MMS/3G LG KG800-Chocolate
LG	One Touch 735i	GPRS/MMS/3G LG KG808Chocolate	GPRS/MMS/3G LG KG808-Chocolate
LG	One Touch 735i	GPRS/MMS/3G LG KG810	GPRS/MMS/3G LG KG-810
LG	One Touch 735i	GPRS/MMS/3G LG KG90	GPRS/MMS/3G LG KG-90
LG	One Touch 735i	GPRS/MMS/3G LG KG920	GPRS/MMS/3G LG KG-920

LG	One Touch 735i	GPRS/MMS/3G LG KP200	GPRS/MMS/3G LG KP-200
LG	One Touch 735i	GPRS/MMS/3G LG KP202	GPRS/MMS/3G LG KP-202
LG	One Touch 735i	GPRS/MMS/3G LG KS10	GPRS/MMS/3G LG KS-10
LG	One Touch 735i	GPRS/MMS/3G LG KU250	GPRS/MMS/3G LG KU-250
LG	One Touch 735i	GPRS/MMS/3G LG KU311	GPRS/MMS/3G LG KU-311
LG	One Touch 735i	GPRS/MMS/3G LG KU580	GPRS/MMS/3G LG KU-580
LG	One Touch 735i	GPRS/MMS/3G LG KU730	GPRS/MMS/3G LG KU-730
LG	One Touch 735i	GPRS/MMS/3G LG KU800	GPRS/MMS/3G LG KU-800
LG	One Touch 735i	GPRS/MMS/3G LG KU830	GPRS/MMS/3G LG KU-830
LG	One Touch 735i	GPRS/MMS/3G LG KU950	GPRS/MMS/3G LG KU-950
LG	One Touch 735i	GPRS/MMS/3G LG KU970Shine	GPRS/MMS/3G LG KU970-Shine
LG	One Touch 735i	GPRS/MMS/3G LG KU990Viewty	GPRS/MMS/3G LG KU990-Viewty
LG	One Touch 735i	GPRS/MMS/3G LG L1100	GPRS/MMS/3G LG L-1100
LG	One Touch 735i	GPRS/MMS/3G LG L1150	GPRS/MMS/3G LG L-1150
LG	One Touch 735i	GPRS/MMS/3G LG L1200	GPRS/MMS/3G LG L-1200
LG	One Touch 735i	GPRS/MMS/3G LG L1400	GPRS/MMS/3G LG L-1400
LG	One Touch 735i	GPRS/MMS/3G LG L1400i	GPRS/MMS/3G LG L-1400i
LG	One Touch 735i	GPRS/MMS/3G LG L3100	GPRS/MMS/3G LG L-3100
LG	One Touch 735i	GPRS/MMS/3G LG L5100	GPRS/MMS/3G LG L-5100
LG	One Touch 735i	GPRS/MMS/3G LG L600v	GPRS/MMS/3G LG L-600v
LG	One Touch 735i	GPRS/MMS/3G LG LG-500	GPRS/MMS/3G LG LG-500
LG	One Touch 735i	GPRS/MMS/3G LG M4300	GPRS/MMS/3G LG M-4300
LG	One Touch 735i	GPRS/MMS/3G LG M4400	GPRS/MMS/3G LG M-4400
LG	One Touch 735i	GPRS/MMS/3G LG M4410	GPRS/MMS/3G LG M-4410
LG	One Touch 735i	GPRS/MMS/3G LG M6100	GPRS/MMS/3G LG M-6100
LG	One Touch 735i	GPRS/MMS/3G LG ME240q	GPRS/MMS/3G LG ME-240q
LG	One Touch 735i	GPRS/MMS/3G LG ME500C	GPRS/MMS/3G LG ME-500C
LG	One Touch 735i	GPRS/MMS/3G LG ME540C	GPRS/MMS/3G LG ME-540C
LG	One Touch 735i	GPRS/MMS/3G LG ME550c	GPRS/MMS/3G LG ME-550c
LG	One Touch 735i	GPRS/MMS/3G LG ME550d	GPRS/MMS/3G LG ME-550d
LG	One Touch 735i	GPRS/MMS/3G LG ME591	GPRS/MMS/3G LG ME-591
LG	One Touch 735i	GPRS/MMS/3G LG ME591d	GPRS/MMS/3G LG ME-591d
LG	One Touch 735i	GPRS/MMS/3G LG ME770c	GPRS/MMS/3G LG ME-770c
LG	One Touch 735i	GPRS/MMS/3G LG ME770d	GPRS/MMS/3G LG ME-770d
LG	One Touch 735i	GPRS/MMS/3G LG ME850cPrada	GPRS/MMS/3G LG ME850c-Prada
LG	One Touch 735i	GPRS/MMS/3G ME850d	GPRS/MMS/3G LG ME-850d
LG	One Touch 735i	GPRS/MMS/3G LG ME970d	GPRS/MMS/3G LG ME-970d
LG	One Touch 735i	GPRS/MMS/3G LG MG100	GPRS/MMS/3G LG MG-100
LG	One Touch 735i	GPRS/MMS/3G LG MG100a	GPRS/MMS/3G LG MG-100a
LG	One Touch 735i	GPRS/MMS/3G LG MG100c	GPRS/MMS/3G LG MG-100c
LG	One Touch 735i	GPRS/MMS/3G LG MG101	GPRS/MMS/3G LG MG-101
LG	One Touch 735i	GPRS/MMS/3G LG MG105	GPRS/MMS/3G LG MG-105
LG	One Touch 735i	GPRS/MMS/3G LG MG110	GPRS/MMS/3G LG MG-110
LG	One Touch 735i	GPRS/MMS/3G LG MG110b	GPRS/MMS/3G LG MG-110b
LG	One Touch 735i	GPRS/MMS/3G LG MG120b	GPRS/MMS/3G LG MG-120b
LG	One Touch 735i	GPRS/MMS/3G LG MG125a	GPRS/MMS/3G LG MG-125a
LG	One Touch 735i	GPRS/MMS/3G LG MG125b	GPRS/MMS/3G LG MG-125b
LG	One Touch 735i	GPRS/MMS/3G LG MG130d	GPRS/MMS/3G LG MG-130d
LG	One Touch 735i	GPRS/MMS/3G LG MG150	GPRS/MMS/3G LG MG-150
LG	One Touch 735i	GPRS/MMS/3G LG MG155	GPRS/MMS/3G LG MG-155
LG	One Touch 735i	GPRS/MMS/3G LG MG155d	GPRS/MMS/3G LG MG-155d
LG	One Touch 735i	GPRS/MMS/3G LG MG170	GPRS/MMS/3G LG MG-170
LG	One Touch 735i	GPRS/MMS/3G LG MG180c	GPRS/MMS/3G LG MG-180c
LG	One Touch 735i	GPRS/MMS/3G LG MG180d	GPRS/MMS/3G LG MG-180d
LG	One Touch 735i	GPRS/MMS/3G LG MG185c	GPRS/MMS/3G LG MG-185c

LG	One Touch 735i	GPRS/MMS/3G LG MG185d	GPRS/MMS/3G LG MG-185d
LG	One Touch 735i	GPRS/MMS/3G LG MG200	GPRS/MMS/3G LG MG-200
LG	One Touch 735i	GPRS/MMS/3G LG MG200C	GPRS/MMS/3G LG MG-200C
LG	One Touch 735i	GPRS/MMS/3G LG MG200d	GPRS/MMS/3G LG MG-200D
LG	One Touch 735i	GPRS/MMS/3G LG MG201d	GPRS/MMS/3G LG MG-201D
LG	One Touch 735i	GPRS/MMS/3G LG MG210c	GPRS/MMS/3G LG MG-210C
LG	One Touch 735i	GPRS/MMS/3G LG MG210d	GPRS/MMS/3G LG MG-210D
LG	One Touch 735i	GPRS/MMS/3G LG MG220c	GPRS/MMS/3G LG MG-220C
LG	One Touch 735i	GPRS/MMS/3G LG MG220d	GPRS/MMS/3G LG MG-220D
LG	One Touch 735i	GPRS/MMS/3G LG MG225d	GPRS/MMS/3G LG MG-225D
LG	One Touch 735i	GPRS/MMS/3G LG MG230d	GPRS/MMS/3G LG MG-230D
LG	One Touch 735i	GPRS/MMS/3G LG MG235c	GPRS/MMS/3G LG MG-235C
LG	One Touch 735i	GPRS/MMS/3G LG MG270	GPRS/MMS/3G LG MG-270
LG	One Touch 735i	GPRS/MMS/3G LG MG280c	GPRS/MMS/3G LG MG-280C
LG	One Touch 735i	GPRS/MMS/3G LG MG280d	GPRS/MMS/3G LG MG-280D
LG	One Touch 735i	GPRS/MMS/3G LG MG296c	GPRS/MMS/3G LG MG-296C
LG	One Touch 735i	GPRS/MMS/3G LG MG300d	GPRS/MMS/3G LG MG-300D
LG	One Touch 735i	GPRS/MMS/3G LG MG320c	GPRS/MMS/3G LG MG-320C
LG	One Touch 735i	GPRS/MMS/3G LG MG320	GPRS/MMS/3G LG MG-320
LG	One Touch 735i	GPRS/MMS/3G LG MG320d	GPRS/MMS/3G LG MG-320D
LG	One Touch 735i	GPRS/MMS/3G LG MG530	GPRS/MMS/3G LG MG-530
LG	One Touch 735i	GPRS/MMS/3G LG MG610c	GPRS/MMS/3G LG MG-610C
LG	One Touch 735i	GPRS/MMS/3G LG MG810c	GPRS/MMS/3G LG MG-810C
LG	One Touch 735i	GPRS/MMS/3G LG MU500	GPRS/MMS/3G LG MU-500
LG	One Touch 735i	GPRS/MMS/3G LG MW560	GPRS/MMS/3G LG MVV-560
LG	One Touch 735i	GPRS/MMS/3G LG P7200	GPRS/MMS/3G LG P-7200
LG	One Touch 735i	GPRS/MMS/3G LG S3500	GPRS/MMS/3G LG S-3500
LG	One Touch 735i	GPRS/MMS/3G LG S5000	GPRS/MMS/3G LG S-5000
LG	One Touch 735i	GPRS/MMS/3G LG S5100	GPRS/MMS/3G LG S-5100
LG	One Touch 735i	GPRS/MMS/3G LG S5200	GPRS/MMS/3G LG S-5200
LG	One Touch 735i	GPRS/MMS/3G LG S5300	GPRS/MMS/3G LG S-5300
LG	One Touch 735i	GPRS/MMS/3G LG T5100	GPRS/MMS/3G LG T-5100
LG	One Touch 735i	GPRS/MMS/3G LG TG300	GPRS/MMS/3G LG TG-300
LG	One Touch 735i	GPRS/MMS/3G LG TU500	GPRS/MMS/3G LG TU-500
LG	One Touch 735i	GPRS/MMS/3G LG U300	GPRS/MMS/3G LG U-300v
LG	One Touch 735i	GPRS/MMS/3G LG U310	GPRS/MMS/3G LG U-310
LG	One Touch 735i	GPRS/MMS/3G LG U400	GPRS/MMS/3G LG U-400
LG	One Touch 735i	GPRS/MMS/3G LG U8100	GPRS/MMS/3G LG U-8100
LG	One Touch 735i	GPRS/MMS/3G LG U8110	GPRS/MMS/3G LG U-8110
LG	One Touch 735i	GPRS/MMS/3G LG U8120	GPRS/MMS/3G LG U-8120
LG	One Touch 735i	GPRS/MMS/3G LG U8130	GPRS/MMS/3G LG U-8130
LG	One Touch 735i	GPRS/MMS/3G LG U8138	GPRS/MMS/3G LG U-8138
LG	One Touch 735i	GPRS/MMS/3G LG U8150	GPRS/MMS/3G LG U-8150
LG	One Touch 735i	GPRS/MMS/3G LG U8180	GPRS/MMS/3G LG U-8180
LG	One Touch 735i	GPRS/MMS/3G LG U8180C	GPRS/MMS/3G LG U-8180C
LG	One Touch 735i	GPRS/MMS/3G LG U8180F	GPRS/MMS/3G LG U-8180F
LG	One Touch 735i	GPRS/MMS/3G LG U830	GPRS/MMS/3G LG U-830
LG	One Touch 735i	GPRS/MMS/3G LG U830C	GPRS/MMS/3G LG U-830C
LG	One Touch 735i	GPRS/MMS/3G LG U8330	GPRS/MMS/3G LG U-8330
LG	One Touch 735i	GPRS/MMS/3G LG U8330C	GPRS/MMS/3G LG U-8330C
LG	One Touch 735i	GPRS/MMS/3G LG U8330i	GPRS/MMS/3G LG U-8330I
LG	One Touch 735i	GPRS/MMS/3G LG U8330T	GPRS/MMS/3G LG U-8330T
LG	One Touch 735i	GPRS/MMS/3G LG U8360	GPRS/MMS/3G LG U-8360
LG	One Touch 735i	GPRS/MMS/3G LG U8360C	GPRS/MMS/3G LG U-8360C
LG	One Touch 735i	GPRS/MMS/3G LG U8380	GPRS/MMS/3G LG U-8380

LG	One Touch 735i	GPRS/MMS/3G LG U8380C	GPRS/MMS/3G LG U-8380C
LG	One Touch 735i	GPRS/MMS/3G LG U8500	GPRS/MMS/3G LG U-8500
LG	One Touch 735i	GPRS/MMS/3G LG U880	GPRS/MMS/3G LG U-880
LG	One Touch 735i	GPRS/MMS/3G LG U880C	GPRS/MMS/3G LG U-880C
LG	One Touch 735i	GPRS/MMS/3G LG U890	GPRS/MMS/3G LG U-890
LG	One Touch 735i	GPRS/MMS/3G LG U890C	GPRS/MMS/3G LG U-890C
LG	One Touch 735i	GPRS/MMS/3G LG U900	GPRS/MMS/3G LG U-900
LG	One Touch 735i	GPRS/MMS/3G LG U960	GPRS/MMS/3G LG U-960
LG	One Touch 735i	GPRS/MMS/3G LG V9000	GPRS/MMS/3G LG V-9000
LG	One Touch 735i	GPRS/MMS/3G LG W3000	GPRS/MMS/3G LG W-3000
LG	One Touch 735i	GPRS/MMS/3G LG W3000S	GPRS/MMS/3G LG W-300S
LG	One Touch 735i	GPRS/MMS/3G LG W5200	GPRS/MMS/3G LG W-5200
LG	One Touch 735i	GPRS/MMS/3G LG W5300	GPRS/MMS/3G LG W-5300
LG	One Touch 735i	GPRS/MMS/3G LG W7000	GPRS/MMS/3G LG W-7000
LG	One Touch 735i	GPRS/MMS/3G LG W7020	GPRS/MMS/3G LG W-7020
LiteOn	One Touch 735i	GPRS/MMS/3G LiteOn B1300	GPRS/MMS/3G LiteOn B-1300
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A1200	GPRS/MMS/3G Motorola A-1200
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A1200e	GPRS/MMS/3G Motorola A-1200E
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A630	GPRS/MMS/3G Motorola A-630
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A728	GPRS/MMS/3G Motorola A-728
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A732	GPRS/MMS/3G Motorola A-732
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A760	GPRS/MMS/3G Motorola A-760
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A760i	GPRS/MMS/3G Motorola A-760I
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A768i	GPRS/MMS/3G Motorola A-768I
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A780	GPRS/MMS/3G Motorola A-780
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A830	GPRS/MMS/3G Motorola A-830
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A835	GPRS/MMS/3G Motorola A-835
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A840	GPRS/MMS/3G Motorola A-840
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A845	GPRS/MMS/3G Motorola A-845
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A860	GPRS/MMS/3G Motorola A-860
Motorola	One Touch 735i	GPRS/MMS/3G Motorola A910	GPRS/MMS/3G Motorola A-910
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C168	GPRS/MMS/3G Motorola C-168
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C168i	GPRS/MMS/3G Motorola C-168I
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C257	GPRS/MMS/3G Motorola C-257
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C261	GPRS/MMS/3G Motorola C-261
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C350	GPRS/MMS/3G Motorola C-350
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C370	GPRS/MMS/3G Motorola C-370
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C375	GPRS/MMS/3G Motorola C-375
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C380	GPRS/MMS/3G Motorola C-380
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C381	GPRS/MMS/3G Motorola C-381
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C381p	GPRS/MMS/3G Motorola C-381P
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C384	GPRS/MMS/3G Motorola C-384
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C385	GPRS/MMS/3G Motorola C-385
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C390	GPRS/MMS/3G Motorola C-390
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C550	GPRS/MMS/3G Motorola C-550
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C650	GPRS/MMS/3G Motorola C-650
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C651	GPRS/MMS/3G Motorola C-651
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C698p	GPRS/MMS/3G Motorola C-698P
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C975	GPRS/MMS/3G Motorola C-975
Motorola	One Touch 735i	GPRS/MMS/3G Motorola C980	GPRS/MMS/3G Motorola C-980
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E1	GPRS/MMS/3G Motorola E-1
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E1000	GPRS/MMS/3G Motorola E-1000
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E1070	GPRS/MMS/3G Motorola E-1070
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E375	GPRS/MMS/3G Motorola E-375
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E380	GPRS/MMS/3G Motorola E-380

Motorola	One Touch 735i	GPRS/MMS/3G Motorola E398	GPRS/MMS/3G Motorola E-398
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E550	GPRS/MMS/3G Motorola E-550
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E680	GPRS/MMS/3G Motorola E-680
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E680i	GPRS/MMS/3G Motorola E-680i
Motorola	One Touch 735i	GPRS/MMS/3G Motorola E770	GPRS/MMS/3G Motorola E-770
Motorola	One Touch 735i	GPRS/MMS/3G Motorola KRZRK1	GPRS/MMS/3G Motorola KRZR-K1
Motorola	One Touch 735i	GPRS/MMS/3G Motorola KRZRK3	GPRS/MMS/3G Motorola KRZR-K3
Motorola	One Touch 735i	GPRS/MMS/3G Motorola KRZRK3m	GPRS/MMS/3G Motorola KRZR-K3m
Motorola	One Touch 735i	GPRS/MMS/3G Motorola L2	GPRS/MMS/3G Motorola L-2
Motorola	One Touch 735i	GPRS/MMS/3G Motorola L6	GPRS/MMS/3G Motorola L-6
Motorola	One Touch 735i	GPRS/MMS/3G Motorola L7	GPRS/MMS/3G Motorola L-7
Motorola	One Touch 735i	GPRS/MMS/3G Motorola M930	GPRS/MMS/3G Motorola M-930
Motorola	One Touch 735i	GPRS/MMS/3G Motorola MPx200	GPRS/MMS/3G Motorola MPX-200
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZR2V8	GPRS/MMS/3G Motorola RAZR2-V8
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZR2V9	GPRS/MMS/3G Motorola RAZR2-V9
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZRmaxxV6	GPRS/MMS/3G Motorola RAZRmaxx-V6
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZRV3e	GPRS/MMS/3G Motorola RAZR-V3e
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZRV3EDGE	GPRS/MMS/3G Motorola RAZR-V3-EDGE
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZRV3r	GPRS/MMS/3G Motorola RAZR-V3r
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZRV3t	GPRS/MMS/3G Motorola RAZR-V3t
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RAZRV3xx	GPRS/MMS/3G Motorola RAZR-V3xx
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RIZRZ3	GPRS/MMS/3G Motorola RIZR-Z3
Motorola	One Touch 735i	GPRS/MMS/3G Motorola RIZRZ8	GPRS/MMS/3G Motorola RIZR-Z8
Motorola	One Touch 735i	GPRS/MMS/3G Motorola ROKRE2	GPRS/MMS/3G Motorola ROKR-E2
Motorola	One Touch 735i	GPRS/MMS/3G Motorola ROKRE6	GPRS/MMS/3G Motorola ROKR-E6
Motorola	One Touch 735i	GPRS/MMS/3G Motorola ROKRW5	GPRS/MMS/3G Motorola ROKR-W5
Motorola	One Touch 735i	GPRS/MMS/3G Motorola ROKRZ6	GPRS/MMS/3G Motorola ROKR-Z6
Motorola	One Touch 735i	GPRS/MMS/3G Motorola SLVRL7e	GPRS/MMS/3G Motorola SLVR-L7e
Motorola	One Touch 735i	GPRS/MMS/3G Motorola SLVRL7i	GPRS/MMS/3G Motorola SLVR-L7i
Motorola	One Touch 735i	GPRS/MMS/3G Motorola SLVRL9	GPRS/MMS/3G Motorola SLVR-L9
Motorola	One Touch 735i	GPRS/MMS/3G Motorola T725	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola T725E	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola U3e	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola U6	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola U9	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V1050	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V1075	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V1100	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V175	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V176	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V177	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V180	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V185	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V186	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V188	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V190	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V191	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V195	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V195s	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V196	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V197	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V220	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V220i	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V226	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V235	

Motorola	One Touch 735i	GPRS/MMS/3G Motorola V237	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V270	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V280	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V290	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V3	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V300	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V303	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V330	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V360	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V360v	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V361	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V365	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V3b	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V3i	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V3iM	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V3x	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V400	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V400p	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V500	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V501	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V505	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V525	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V535	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V540	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V545	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V547	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V550	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V551	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V555	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V557	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V557p	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V560	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V6	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V600	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V600i	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V620	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V635	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V690	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V750	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V8	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V80	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V872	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V878	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V975	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola V980	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola W206	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola W213	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola W220	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola W370	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola W371	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola W375	
Motorola	One Touch 735i	GPRS/MMS/3G Motorola W510	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 1116	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 1650	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2610	

Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2610b	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2626	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2630	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2650	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2651	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2652	
Nokia	One Touch 735i	GPRS/MMS/3G Nokia 2660	
Nokia	3100	GPRS/MMS/3G Nokia 3100	
Nokia	3100b	GPRS/MMS/3G Nokia 3100b	
Nokia	3108	GPRS/MMS/3G Nokia 3108	
Nokia	3109 classic	GPRS/MMS/3G Nokia 3109classic	GPRS/MMS/3G Nokia 3109-classic
Nokia	3110 classic	GPRS/MMS/3G Nokia 3110classic	GPRS/MMS/3G Nokia 3110-classic
Nokia	3120	GPRS/MMS/3G Nokia 3120	
Nokia	3120b	GPRS/MMS/3G Nokia 3120b	
Nokia	3128	GPRS/MMS/3G Nokia 3128	
Nokia	3129	GPRS/MMS/3G Nokia 3129	
Nokia	3200	GPRS/MMS/3G Nokia 3200	
Nokia	3200b	GPRS/MMS/3G Nokia 3200b	
Nokia	3220	GPRS/MMS/3G Nokia 3220	
Nokia	3220b	GPRS/MMS/3G Nokia 3220b	
Nokia	3230	GPRS/MMS/3G Nokia 3230	
Nokia	3250	GPRS/MMS/3G Nokia 3250	
Nokia	3300	GPRS/MMS/3G Nokia 3300	
Nokia	3300a	GPRS/MMS/3G Nokia 3300a	
Nokia	3300b	GPRS/MMS/3G Nokia 3300b	
Nokia	3310	GPRS/MMS/3G Nokia 3310	
Nokia	3350	GPRS/MMS/3G Nokia 3350	
Nokia	3410	GPRS/MMS/3G Nokia 3410	
Nokia	3500 classic	GPRS/MMS/3G Nokia 3500classic	GPRS/MMS/3G Nokia 3500-classic
Nokia	3500 classic b	GPRS/MMS/3G Nokia 3500classicb	GPRS/MMS/3G Nokia 3500-classicb
Nokia	3510	GPRS/MMS/3G Nokia 3510	
Nokia	3510i	GPRS/MMS/3G Nokia 3510i	
Nokia	3530	GPRS/MMS/3G Nokia 3530	
Nokia	3590	GPRS/MMS/3G Nokia 3590	
Nokia	3595	GPRS/MMS/3G Nokia 3595	
Nokia	3600	GPRS/MMS/3G Nokia 3600	
Nokia	3620	GPRS/MMS/3G Nokia 3620	
Nokia	3650	GPRS/MMS/3G Nokia 3650	
Nokia	3660	GPRS/MMS/3G Nokia 3660	
Nokia	5070	GPRS/MMS/3G Nokia 5070	
Nokia	5070b	GPRS/MMS/3G Nokia 5070b	
Nokia	5100	GPRS/MMS/3G Nokia 5100	
Nokia	5100 Americas	GPRS/MMS/3G Nokia 5100Americas	GPRS/MMS/3G Nokia 5100-Americas
Nokia	5140	GPRS/MMS/3G Nokia 5140	
Nokia	5140b	GPRS/MMS/3G Nokia 5140b	
Nokia	5140i	GPRS/MMS/3G Nokia 5140i	
Nokia	5200	GPRS/MMS/3G Nokia 5200	
Nokia	5200b	GPRS/MMS/3G Nokia 5200b	
Nokia	5210	GPRS/MMS/3G Nokia 5210	
Nokia	5300	GPRS/MMS/3G Nokia 5300	
Nokia	5300b	GPRS/MMS/3G Nokia 5300b	
Nokia	5310	GPRS/MMS/3G Nokia 5310	
Nokia	5310b XpressMusic	GPRS/MMS/3G Nokia 5310bXpressMusic	GPRS/MMS/3G Nokia 5310b-XpressMusic
Nokia	5500d	GPRS/MMS/3G Nokia 5500d	

Nokia	5500 Sport	GPRS/MMS/3G Nokia 5500Sport	GPRS/MMS/3G Nokia 5500-Sport
Nokia	5510	GPRS/MMS/3G Nokia 5510	
Nokia	5610	GPRS/MMS/3G Nokia 5610	
Nokia	5700	GPRS/MMS/3G Nokia 5700	
Nokia	5700 XpressMusic	GPRS/MMS/3G Nokia 5700XpressMusic	GPRS/MMS/3G Nokia 5700-XpressMusic
Nokia	6010	GPRS/MMS/3G Nokia 6010	
Nokia	6020	GPRS/MMS/3G Nokia 6020	
Nokia	6020b	GPRS/MMS/3G Nokia 6020b	
Nokia	6021	GPRS/MMS/3G Nokia 6021	
Nokia	6030	GPRS/MMS/3G Nokia 6030	
Nokia	6030b	GPRS/MMS/3G Nokia 6030b	
Nokia	6060	GPRS/MMS/3G Nokia 6060	
Nokia	6060v	GPRS/MMS/3G Nokia 6060v	
Nokia	6061	GPRS/MMS/3G Nokia 6061	
Nokia	6061b	GPRS/MMS/3G Nokia 6061b	
Nokia	6062	GPRS/MMS/3G Nokia 6062	
Nokia	6070	GPRS/MMS/3G Nokia 6070	
Nokia	6070b	GPRS/MMS/3G Nokia 6070b	
Nokia	6080	GPRS/MMS/3G Nokia 6080	
Nokia	6080b	GPRS/MMS/3G Nokia 6080b	
Nokia	6085	GPRS/MMS/3G Nokia 6085	
Nokia	6086	GPRS/MMS/3G Nokia 6086	
Nokia	6100	GPRS/MMS/3G Nokia 6100	
Nokia	6101	GPRS/MMS/3G Nokia 6101	
Nokia	6101b	GPRS/MMS/3G Nokia 6101b	
Nokia	6102	GPRS/MMS/3G Nokia 6102	
Nokia	6102b	GPRS/MMS/3G Nokia 6102b	
Nokia	6102h	GPRS/MMS/3G Nokia 6102h	
Nokia	6102i	GPRS/MMS/3G Nokia 6102i	
Nokia	6103	GPRS/MMS/3G Nokia 6103	
Nokia	6103b	GPRS/MMS/3G Nokia 6103b	
Nokia	6108	GPRS/MMS/3G Nokia 6108	
Nokia	6110 Navigator	GPRS/MMS/3G Nokia 6110Navigator	GPRS/MMS/3G Nokia 6110-Navigator
Nokia	6111	GPRS/MMS/3G Nokia 6111	
Nokia	6120 Classic	GPRS/MMS/3G Nokia 6120Classic	GPRS/MMS/3G Nokia 6120-Classic
Nokia	6121 classic	GPRS/MMS/3G Nokia 6121classic	GPRS/MMS/3G Nokia 6121-classic
Nokia	6125	GPRS/MMS/3G Nokia 6125	
Nokia	6126	GPRS/MMS/3G Nokia 6126	
Nokia	6131	GPRS/MMS/3G Nokia 6131	
Nokia	6131 NFC	GPRS/MMS/3G Nokia 6131NFC	GPRS/MMS/3G Nokia 6131-NFC
Nokia	6133	GPRS/MMS/3G Nokia 6133	
Nokia	6133b	GPRS/MMS/3G Nokia 6133b	
Nokia	6136	GPRS/MMS/3G Nokia 6136	
Nokia	6151	GPRS/MMS/3G Nokia 6151	
Nokia	6170	GPRS/MMS/3G Nokia 6170	
Nokia	6170b	GPRS/MMS/3G Nokia 6170b	
Nokia	6200	GPRS/MMS/3G Nokia 6200	
Nokia	6210	GPRS/MMS/3G Nokia 6210	
Nokia	6220	GPRS/MMS/3G Nokia 6220	
Nokia	6230	GPRS/MMS/3G Nokia 6230	
Nokia	6230b	GPRS/MMS/3G Nokia 6230b	
Nokia	6230i	GPRS/MMS/3G Nokia 6230i	
Nokia	6233	GPRS/MMS/3G Nokia 6233	
Nokia	6234	GPRS/MMS/3G Nokia 6234	
Nokia	6250	GPRS/MMS/3G Nokia 6250	

Nokia	6260	GPRS/MMS/3G Nokia 6260	
Nokia	6267	GPRS/MMS/3G Nokia 6267	
Nokia	6270	GPRS/MMS/3G Nokia 6270	
Nokia	6280	GPRS/MMS/3G Nokia 6280	
Nokia	6282	GPRS/MMS/3G Nokia 6282	
Nokia	6288	GPRS/MMS/3G Nokia 6288	
Nokia	6290	GPRS/MMS/3G Nokia 6290	
Nokia	6300	GPRS/MMS/3G Nokia 6300	
Nokia	6300b	GPRS/MMS/3G Nokia 6300b	
Nokia	6301	GPRS/MMS/3G Nokia 6301	
Nokia	6310	GPRS/MMS/3G Nokia 6310	
Nokia	6310i	GPRS/MMS/3G Nokia 6310i	
Nokia	6340	GPRS/MMS/3G Nokia 6340	
Nokia	6340i	GPRS/MMS/3G Nokia 6340i	
Nokia	6500	GPRS/MMS/3G Nokia 6500	
Nokia	6500 classic	GPRS/MMS/3G Nokia 6500classic	GPRS/MMS/3G Nokia 6500-classic
Nokia	6500 slide	GPRS/MMS/3G Nokia 6500slide	GPRS/MMS/3G Nokia 6500-slide
Nokia	6510	GPRS/MMS/3G Nokia 6510	
Nokia	6555	GPRS/MMS/3G Nokia 6555	
Nokia	6555b	GPRS/MMS/3G Nokia 6555b	
Nokia	6590	GPRS/MMS/3G Nokia 6590	
Nokia	6590i	GPRS/MMS/3G Nokia 6590i	
Nokia	6600	GPRS/MMS/3G Nokia 6600	
Nokia	6610	GPRS/MMS/3G Nokia 6610	
Nokia	6610i	GPRS/MMS/3G Nokia 6610i	
Nokia	6620	GPRS/MMS/3G Nokia 6620	
Nokia	6630	GPRS/MMS/3G Nokia 6630	
Nokia	6650	GPRS/MMS/3G Nokia 6650	
Nokia	6651	GPRS/MMS/3G Nokia 6651	
Nokia	6670	GPRS/MMS/3G Nokia 6670	
Nokia	6670b	GPRS/MMS/3G Nokia 6670b	
Nokia	6679	GPRS/MMS/3G Nokia 6679	
Nokia	6680	GPRS/MMS/3G Nokia 6680	
Nokia	6681	GPRS/MMS/3G Nokia 6681	
Nokia	6682	GPRS/MMS/3G Nokia 6682	
Nokia	6708	GPRS/MMS/3G Nokia 6708	
Nokia	6800	GPRS/MMS/3G Nokia 6800	
Nokia	6800a	GPRS/MMS/3G Nokia 6800a	
Nokia	6801	GPRS/MMS/3G Nokia 6801	
Nokia	6810	GPRS/MMS/3G Nokia 6810	
Nokia	6820	GPRS/MMS/3G Nokia 6820	
Nokia	6820b	GPRS/MMS/3G Nokia 6820b	
Nokia	6822a	GPRS/MMS/3G Nokia 6822a	
Nokia	6822b	GPRS/MMS/3G Nokia 6822b	
Nokia	7110	GPRS/MMS/3G Nokia 7110	
Nokia	7190	GPRS/MMS/3G Nokia 7190	
Nokia	7200	GPRS/MMS/3G Nokia 7200	
Nokia	7210	GPRS/MMS/3G Nokia 7210	
Nokia	7250	GPRS/MMS/3G Nokia 7250	
Nokia	7250i	GPRS/MMS/3G Nokia 7250i	
Nokia	7260	GPRS/MMS/3G Nokia 7260	
Nokia	7270	GPRS/MMS/3G Nokia 7270	
Nokia	7280	GPRS/MMS/3G Nokia 7280	
Nokia	7360	GPRS/MMS/3G Nokia 7360	
Nokia	7370	GPRS/MMS/3G Nokia 7370	

Nokia	7373	GPRS/MMS/3G Nokia 7373	
Nokia	7380	GPRS/MMS/3G Nokia 7380	
Nokia	7390	GPRS/MMS/3G Nokia 7390	
Nokia	7500 Prism	GPRS/MMS/3G Nokia 7500Prism	GPRS/MMS/3G Nokia 7500-Prism
Nokia	7600	GPRS/MMS/3G Nokia 7600	
Nokia	7610	GPRS/MMS/3G Nokia 7610	
Nokia	7610b	GPRS/MMS/3G Nokia 7610b	
Nokia	7650	GPRS/MMS/3G Nokia 7650	
Nokia	7710	GPRS/MMS/3G Nokia 7710	
Nokia	7900 Prism	GPRS/MMS/3G Nokia 7900Prism	GPRS/MMS/3G Nokia 7900-Prism
Nokia	8310	GPRS/MMS/3G Nokia 8310	
Nokia	8390	GPRS/MMS/3G Nokia 8390	
Nokia	8600 Luna	GPRS/MMS/3G Nokia 8600Luna	GPRS/MMS/3G Nokia
Nokia	8800	GPRS/MMS/3G Nokia 8800	
Nokia	8800 Arte	GPRS/MMS/3G Nokia 8800Arte	GPRS/MMS/3G Nokia 8800-Arte
Nokia	8800d	GPRS/MMS/3G Nokia 8800d	
Nokia	8800 Sirocco	GPRS/MMS/3G Nokia 8800Sirocco	GPRS/MMS/3G Nokia 8800-Sirocco
Nokia	8801	GPRS/MMS/3G Nokia 8801	
Nokia	8855	GPRS/MMS/3G Nokia 8855	
Nokia	8910	GPRS/MMS/3G Nokia 8910	
Nokia	8910i	GPRS/MMS/3G Nokia 8910i	
Nokia	9110	GPRS/MMS/3G Nokia 9110	
Nokia	9110i	GPRS/MMS/3G Nokia 9110i	
Nokia	9210	GPRS/MMS/3G Nokia 9210	
Nokia	9210i	GPRS/MMS/3G Nokia 9210i	
Nokia	9290	GPRS/MMS/3G Nokia 9290	
Nokia	9300	GPRS/MMS/3G Nokia 9300	
Nokia	9300b	GPRS/MMS/3G Nokia 9300b	
Nokia	9300i	GPRS/MMS/3G Nokia 9300i	
Nokia	9500	GPRS/MMS/3G Nokia 9500	
Nokia	9500b	GPRS/MMS/3G Nokia 9500b	
Nokia	E50	GPRS/MMS/3G Nokia E50	
Nokia	E50-2	GPRS/MMS/3G Nokia E50-2	
Nokia	E51	GPRS/MMS/3G Nokia E51	
Nokia	E60	GPRS/MMS/3G Nokia E60	
Nokia	E61	GPRS/MMS/3G Nokia E61	
Nokia	E61i	GPRS/MMS/3G Nokia E61i	
Nokia	E61i-2	GPRS/MMS/3G Nokia E61i-2	
Nokia	E62	GPRS/MMS/3G Nokia E62	
Nokia	E65	GPRS/MMS/3G Nokia E65	
Nokia	E70	GPRS/MMS/3G Nokia E70	
Nokia	E70-2	GPRS/MMS/3G Nokia E70-2	
Nokia	E90	GPRS/MMS/3G Nokia E90	
Nokia	N70	GPRS/MMS/3G Nokia N70	
Nokia	N70-5	GPRS/MMS/3G Nokia N70-5	
Nokia	N71	GPRS/MMS/3G Nokia N71	
Nokia	N71-1	GPRS/MMS/3G Nokia N71-1	
Nokia	N72	GPRS/MMS/3G Nokia N72	
Nokia	N73	GPRS/MMS/3G Nokia N73	
Nokia	N73-5	GPRS/MMS/3G Nokia N73-5	
Nokia	N75	GPRS/MMS/3G Nokia N75	
Nokia	N76	GPRS/MMS/3G Nokia N76	
Nokia	N77	GPRS/MMS/3G Nokia N77	
Nokia	N80	GPRS/MMS/3G Nokia N80	
Nokia	N80-1	GPRS/MMS/3G Nokia N80-1	

Nokia	N80-3	GPRS/MMS/3G Nokia N80-3	
Nokia	N81	GPRS/MMS/3G Nokia N81	
Nokia	N81-3	GPRS/MMS/3G Nokia N81-3	
Nokia	N82	GPRS/MMS/3G Nokia N82	
Nokia	N90	GPRS/MMS/3G Nokia N90	
Nokia	N91	GPRS/MMS/3G Nokia N91	
Nokia	N91-6	GPRS/MMS/3G Nokia N91-6	
Nokia	N91 8GB	GPRS/MMS/3G Nokia N918GB	GPRS/MMS/3G Nokia N91-8GB
Nokia	N92	GPRS/MMS/3G Nokia N92	
Nokia	N93	GPRS/MMS/3G Nokia N93	
Nokia	N93i	GPRS/MMS/3G Nokia N93i	
Nokia	N95	GPRS/MMS/3G Nokia N95	
Nokia	N95-3	GPRS/MMS/3G Nokia N95-3	
Nokia	N95 8GB	GPRS/MMS/3G Nokia N958GB	GPRS/MMS/3G Nokia N95-8GB
Nokia	N-Gage	GPRS/MMS/3G Nokia N-Gage	
Nokia	N-Gage QD	GPRS/MMS/3G Nokia N-GageQD	GPRS/MMS/3G Nokia N-Gage-QD
Nokia	Remote Camera	GPRS/MMS/3G Nokia RemoteCamera	GPRS/MMS/3G Nokia Remote-Camera
O2	Ice	GPRS/MMS/3G O2 Ice	
O2	Jet	GPRS/MMS/3G O2 Jet	
Orange	SPV E100	GPRS/MMS/3G Orange SPVE100	GPRS/MMS/3G Orange SPV-E100
Panasonic	A200	GPRS/MMS/3G Panasonic A200	
Panasonic	A210	GPRS/MMS/3G Panasonic A210	
Panasonic	G50	GPRS/MMS/3G Panasonic G50	
Panasonic	G51E	GPRS/MMS/3G Panasonic G51E	
Panasonic	G51M	GPRS/MMS/3G Panasonic G51M	
Panasonic	G51U	GPRS/MMS/3G Panasonic G51U	
Panasonic	G60	GPRS/MMS/3G Panasonic G60	
Panasonic	G70E	GPRS/MMS/3G Panasonic G70E	
Panasonic	G70S	GPRS/MMS/3G Panasonic G70S	
Panasonic	GD86	GPRS/MMS/3G Panasonic GD86	
Panasonic	GD86A	GPRS/MMS/3G Panasonic GD86A	
Panasonic	GD87	GPRS/MMS/3G Panasonic GD87	
Panasonic	GD88	GPRS/MMS/3G Panasonic GD88	
Panasonic	GU87	GPRS/MMS/3G Panasonic GU87	
Panasonic	MX6	GPRS/MMS/3G Panasonic MX6	
Panasonic	MX7	GPRS/MMS/3G Panasonic MX7	
Panasonic	SA6	GPRS/MMS/3G Panasonic SA6	
Panasonic	SA7	GPRS/MMS/3G Panasonic SA7	
Panasonic	SC3	GPRS/MMS/3G Panasonic SC3	
Panasonic	VS2	GPRS/MMS/3G Panasonic VS2	
Panasonic	VS3	GPRS/MMS/3G Panasonic VS3	
Panasonic	VS6	GPRS/MMS/3G Panasonic VS6	
Panasonic	VS7	GPRS/MMS/3G Panasonic VS7	
Panasonic	X11	GPRS/MMS/3G Panasonic X11	
Panasonic	X300	GPRS/MMS/3G Panasonic X300	
Panasonic	X400	GPRS/MMS/3G Panasonic X400	
Panasonic	X66	GPRS/MMS/3G Panasonic X66	
Panasonic	X68	GPRS/MMS/3G Panasonic X68	
Panasonic	X70	GPRS/MMS/3G Panasonic X70	
Panasonic	X700	GPRS/MMS/3G Panasonic X700	
Panasonic	X77	GPRS/MMS/3G Panasonic X77	
Panasonic	X800	GPRS/MMS/3G Panasonic X800	
Panasonic	X88	GPRS/MMS/3G Panasonic X88	
Pantech	PG-1000	GPRS/MMS/3G Pantech PG-1000	
Pantech	PG-1000S	GPRS/MMS/3G Pantech PG-1000S	

Pantech	PG-1300	GPRS/MMS/3G Pantech PG-1300	
Pantech	PG-1300V	GPRS/MMS/3G Pantech PG-1300V	
Pantech	PG-1600	GPRS/MMS/3G Pantech PG-1600	
Pantech	PG-1610	GPRS/MMS/3G Pantech PG-1610	
Pantech	PG-3200	GPRS/MMS/3G Pantech PG-3200	
Pantech	PG-3210	GPRS/MMS/3G Pantech PG-3210	
Philips	162	GPRS/MMS/3G Philips 162	
Philips	330	GPRS/MMS/3G Philips 330	
Philips	350	GPRS/MMS/3G Philips 350	
Philips	355	GPRS/MMS/3G Philips 355	
Philips	362	GPRS/MMS/3G Philips 362	
Philips	390	GPRS/MMS/3G Philips 390	
Philips	530	GPRS/MMS/3G Philips 530	
Philips	535	GPRS/MMS/3G Philips 535	
Philips	550	GPRS/MMS/3G Philips 550	
Philips	568	GPRS/MMS/3G Philips 568	
Philips	588	GPRS/MMS/3G Philips 588	
Philips	630	GPRS/MMS/3G Philips 630	
Philips	636	GPRS/MMS/3G Philips 636	
Philips	639	GPRS/MMS/3G Philips 639	
Philips	650	GPRS/MMS/3G Philips 650	
Philips	655	GPRS/MMS/3G Philips 655	
Philips	659	GPRS/MMS/3G Philips 659	
Philips	755	GPRS/MMS/3G Philips 755	
Philips	759	GPRS/MMS/3G Philips 759	
Philips	760	GPRS/MMS/3G Philips 760	
Philips	768	GPRS/MMS/3G Philips 768	
Philips	855	GPRS/MMS/3G Philips 855	
Philips	859	GPRS/MMS/3G Philips 859	
Philips	892	GPRS/MMS/3G Philips 892	
Philips	960	GPRS/MMS/3G Philips 960	
Philips	Fisio 820	GPRS/MMS/3G Philips Fisio820	GPRS/MMS/3G Philips Fisio-820
Philips	S800	GPRS/MMS/3G Philips S800	
Philips	S890	GPRS/MMS/3G Philips S890	
Philips	Xenium 9@9++	GPRS/MMS/3G Philips Xenium9@9++	GPRS/MMS/3G Philips Xenium-9@9++
Philips	Xenium 9@98	GPRS/MMS/3G Philips Xenium9@98	GPRS/MMS/3G Philips Xenium-9@98
Philips	Xenium 9@9e	GPRS/MMS/3G Philips Xenium9@9e	GPRS/MMS/3G Philips Xenium-9@9e
Philips	Xenium 9@9g	GPRS/MMS/3G Philips Xenium9@9g	GPRS/MMS/3G Philips Xenium-9@9g
Philips	Xenium 9@9z	GPRS/MMS/3G Philips Xenium9@9z	GPRS/MMS/3G Philips Xenium-9@9z
Qtek	1010	GPRS/MMS/3G Qtek 1010	
Qtek	7070	GPRS/MMS/3G Qtek 7070	
Sagem	my400v	GPRS/MMS/3G Sagem my400v	
Sagem	my401v	GPRS/MMS/3G Sagem my401v	
Sagem	my700X	GPRS/MMS/3G Sagem my700X	
Sagem	myC4-2	GPRS/MMS/3G Sagem myC4-2	GPRS/MMS/3G Sagem myC42
Sagem	myC5-2	GPRS/MMS/3G Sagem myC5-2	GPRS/MMS/3G Sagem myc52
Sagem	myC5-2v	GPRS/MMS/3G Sagem myC5-2v	GPRS/MMS/3G Sagem myc52v
Sagem	myC5-3	GPRS/MMS/3G Sagem myC5-3	GPRS/MMS/3G Sagem myc53
Sagem	myT-55	GPRS/MMS/3G Sagem myT-55	GPRS/MMS/3G Sagem myt55
Sagem	MyV-55	GPRS/MMS/3G Sagem MyV-55	GPRS/MMS/3G Sagem myv55
Sagem	myV-56	GPRS/MMS/3G Sagem myV-56	GPRS/MMS/3G Sagem myv56
Sagem	myV-65	GPRS/MMS/3G Sagem myV-65	GPRS/MMS/3G Sagem myv65
Sagem	myV-75	GPRS/MMS/3G Sagem myV-75	GPRS/MMS/3G Sagem myv75
Sagem	myV-76	GPRS/MMS/3G Sagem myV-76	GPRS/MMS/3G Sagem myv76
Sagem	myV-85	GPRS/MMS/3G Sagem myV-85	GPRS/MMS/3G Sagem myv85

Sagem	myX3-3	GPRS/MMS/3G Sagem myX3-3	GPRS/MMS/3G Sagem myx33
Sagem	myX-4	GPRS/MMS/3G Sagem myX-4	GPRS/MMS/3G Sagem myx4
Sagem	myX5-2	GPRS/MMS/3G Sagem myX5-2	GPRS/MMS/3G Sagem myx53
Sagem	myX5-3	GPRS/MMS/3G Sagem myX5-3	GPRS/MMS/3G Sagem myx53
Sagem	myX6-2	GPRS/MMS/3G Sagem myX6-2	GPRS/MMS/3G Sagem myx62
Sagem	MyX-7	GPRS/MMS/3G Sagem MyX-7	GPRS/MMS/3G Sagem myx7
Sagem	myX-8	GPRS/MMS/3G Sagem myX-8	GPRS/MMS/3G Sagem myx8
Sagem	myX-85	GPRS/MMS/3G Sagem myX-85	GPRS/MMS/3G Sagem myx85
Sagem	myZ-5	GPRS/MMS/3G Sagem myZ-5	GPRS/MMS/3G Sagem myz5
Samsung	E830	GPRS/MMS/3G Samsung E830	GPRS/MMS/3G Samsung e-830
Samsung	SCH-A790	GPRS/MMS/3G Samsung SCH-A790	GPRS/MMS/3G Samsung SCHA790
Samsung	SCH-A795	GPRS/MMS/3G Samsung SCH-A795	GPRS/MMS/3G Samsung SCHA795
Samsung	Serene	GPRS/MMS/3G Samsung Serene	
Samsung	SGH-A117	GPRS/MMS/3G Samsung SGH-A117	GPRS/MMS/3G Samsung SGHA117
Samsung	SGH-A127	GPRS/MMS/3G Samsung SGH-A127	GPRS/MMS/3G Samsung SGHA127
Samsung	SGH-A436	GPRS/MMS/3G Samsung SGH-A436	GPRS/MMS/3G Samsung SGHA436
Samsung	SGH-A437	GPRS/MMS/3G Samsung SGH-A437	GPRS/MMS/3G Samsung SGHA437
Samsung	SGH-A500	GPRS/MMS/3G Samsung SGH-A500	GPRS/MMS/3G Samsung SGHA500
Samsung	SGH-A516	GPRS/MMS/3G Samsung SGH-A516	GPRS/MMS/3G Samsung SGHA516
Samsung	SGH-A517	GPRS/MMS/3G Samsung SGH-A517	GPRS/MMS/3G Samsung SGHA517
Samsung	SGH-A617	GPRS/MMS/3G Samsung SGH-A617	GPRS/MMS/3G Samsung SGHA617
Samsung	SGH-A701	GPRS/MMS/3G Samsung SGH-A701	GPRS/MMS/3G Samsung SGHA701
Samsung	SGH-A706	GPRS/MMS/3G Samsung SGH-A706	GPRS/MMS/3G Samsung SGHA706
Samsung	SGH-A707	GPRS/MMS/3G Samsung SGH-A707	GPRS/MMS/3G Samsung SGHA707
Samsung	SGH-A707C	GPRS/MMS/3G Samsung SGH-A707C	GPRS/MMS/3G Samsung SGHA707C
Samsung	SGH-A717	GPRS/MMS/3G Samsung SGH-A717	GPRS/MMS/3G Samsung SGHA717
Samsung	SGH-A727	GPRS/MMS/3G Samsung SGH-A727	GPRS/MMS/3G Samsung SGHA727
Samsung	SGH-C130	GPRS/MMS/3G Samsung SGH-C130	GPRS/MMS/3G Samsung SGHC130
Samsung	SGH-C138	GPRS/MMS/3G Samsung SGH-C138	GPRS/MMS/3G Samsung SGHC138
Samsung	SGH-C140	GPRS/MMS/3G Samsung SGH-C140	GPRS/MMS/3G Samsung SGHC140
Samsung	SGH-C140i	GPRS/MMS/3G Samsung SGH-C140i	GPRS/MMS/3G Samsung SGHC140i
Samsung	SGH-C148	GPRS/MMS/3G Samsung SGH-C148	GPRS/MMS/3G Samsung SGH
Samsung	SGH-C160	GPRS/MMS/3G Samsung SGH-C160	GPRS/MMS/3G Samsung SGHC160
Samsung	SGH-C160L	GPRS/MMS/3G Samsung SGH-C160L	GPRS/MMS/3G Samsung SGHC160L
Samsung	SGH-C160M	GPRS/MMS/3G Samsung SGH-C160M	GPRS/MMS/3G Samsung SGHC160M
Samsung	SGH-C161	GPRS/MMS/3G Samsung SGH-C161	GPRS/MMS/3G Samsung SGHC161
Samsung	SGH-C165	GPRS/MMS/3G Samsung SGH-C165	GPRS/MMS/3G Samsung SGHC165
Samsung	SGH-C166	GPRS/MMS/3G Samsung SGH-C166	GPRS/MMS/3G Samsung SGHC166
Samsung	SGH-C168	GPRS/MMS/3G Samsung SGH-C168	GPRS/MMS/3G Samsung SGHC168
Samsung	SGH-C170	GPRS/MMS/3G Samsung SGH-C170	GPRS/MMS/3G Samsung SGHC170
Samsung	SGH-C178	GPRS/MMS/3G Samsung SGH-C178	GPRS/MMS/3G Samsung SGHC178
Samsung	SGH-C180	GPRS/MMS/3G Samsung SGH-C180	GPRS/MMS/3G Samsung SGHC180
Samsung	SGH-C188	GPRS/MMS/3G Samsung SGH-C188	GPRS/MMS/3G Samsung SGHC188
Samsung	SGH-C200	GPRS/MMS/3G Samsung SGH-C200	GPRS/MMS/3G Samsung SGHC200
Samsung	SGH-C200C	GPRS/MMS/3G Samsung SGH-C200C	GPRS/MMS/3G Samsung SGHC200C
Samsung	SGH-C200N	GPRS/MMS/3G Samsung SGH-C200N	GPRS/MMS/3G Samsung SGHC200N
Samsung	SGH-C200S	GPRS/MMS/3G Samsung SGH-C200S	GPRS/MMS/3G Samsung SGHC200S
Samsung	SGH-C207	GPRS/MMS/3G Samsung SGH-C207	GPRS/MMS/3G Samsung SGHC207
Samsung	SGH-C207L	GPRS/MMS/3G Samsung SGH-C207L	GPRS/MMS/3G Samsung SGHC207L
Samsung	SGH-C208	GPRS/MMS/3G Samsung SGH-C208	GPRS/MMS/3G Samsung SGHC208
Samsung	SGH-C210	GPRS/MMS/3G Samsung SGH-C210	GPRS/MMS/3G Samsung SGHC210
Samsung	SGH-C210C	GPRS/MMS/3G Samsung SGH-C210C	GPRS/MMS/3G Samsung SGHC210C
Samsung	SGH-C210S	GPRS/MMS/3G Samsung SGH-C210S	GPRS/MMS/3G Samsung SGHC210S
Samsung	SGH-C216	GPRS/MMS/3G Samsung SGH-C216	GPRS/MMS/3G Samsung SGHC216
Samsung	SGH-C218	GPRS/MMS/3G Samsung SGH-C218	GPRS/MMS/3G Samsung SGHC218

Samsung	SGH-C225	GPRS/MMS/3G Samsung SGH-C225	GPRS/MMS/3G Samsung SGHC225
Samsung	SGH-C230	GPRS/MMS/3G Samsung SGH-C230	GPRS/MMS/3G Samsung SGHC230
Samsung	SGH-C230C	GPRS/MMS/3G Samsung SGH-C230C	GPRS/MMS/3G Samsung SGHC230C
Samsung	SGH-C238	GPRS/MMS/3G Samsung SGH-C238	GPRS/MMS/3G Samsung SGHC238
Samsung	SGH-C240	GPRS/MMS/3G Samsung SGH-C240	GPRS/MMS/3G Samsung SGHC240
Samsung	SGH-C240L	GPRS/MMS/3G Samsung SGH-C240L	GPRS/MMS/3G Samsung SGHC240L
Samsung	SGH-C250	GPRS/MMS/3G Samsung SGH-C250	GPRS/MMS/3G Samsung SGHC250
Samsung	SGH-C258	GPRS/MMS/3G Samsung SGH-C258	GPRS/MMS/3G Samsung SGHC258
Samsung	SGH-C260	GPRS/MMS/3G Samsung SGH-C260	GPRS/MMS/3G Samsung SGHC260
Samsung	SGH-C260L	GPRS/MMS/3G Samsung SGH-C260L	GPRS/MMS/3G Samsung SGHC260L
Samsung	SGH-C260M	GPRS/MMS/3G Samsung SGH-C260M	GPRS/MMS/3G Samsung SGHC260M
Samsung	SGH-C266	GPRS/MMS/3G Samsung SGH-C266	GPRS/MMS/3G Samsung SGHC266
Samsung	SGH-C266L	GPRS/MMS/3G Samsung SGH-C266L	GPRS/MMS/3G Samsung SGHC266L
Samsung	SGH-C268	GPRS/MMS/3G Samsung SGH-C268	GPRS/MMS/3G Samsung SGHC268
Samsung	SGH-C300	GPRS/MMS/3G Samsung SGH-C300	GPRS/MMS/3G Samsung SGHC300
Samsung	SGH-C306	GPRS/MMS/3G Samsung SGH-C306	GPRS/MMS/3G Samsung SGHC306
Samsung	SGH-C308	GPRS/MMS/3G Samsung SGH-C308	GPRS/MMS/3G Samsung SGHC308
Samsung	SGH-C327	GPRS/MMS/3G Samsung SGH-C327	GPRS/MMS/3G Samsung SGHC327
Samsung	SGH-C400	GPRS/MMS/3G Samsung SGH-C400	GPRS/MMS/3G Samsung SGHC400
Samsung	SGH-C400L	GPRS/MMS/3G Samsung SGH-C400L	GPRS/MMS/3G Samsung SGHC400L
Samsung	SGH-C406	GPRS/MMS/3G Samsung SGH-C406	GPRS/MMS/3G Samsung SGHC406
Samsung	SGH-C406L	GPRS/MMS/3G Samsung SGH-C406L	GPRS/MMS/3G Samsung SGHC406L
Samsung	SGH-C408	GPRS/MMS/3G Samsung SGH-C408	GPRS/MMS/3G Samsung SGHC408
Samsung	SGH-C416	GPRS/MMS/3G Samsung SGH-C416	GPRS/MMS/3G Samsung SGHC416
Samsung	SGH-C417	GPRS/MMS/3G Samsung SGH-C417	GPRS/MMS/3G Samsung SGHC417
Samsung	SGH-C420	GPRS/MMS/3G Samsung SGH-C420	GPRS/MMS/3G Samsung SGHC420
Samsung	SGH-C420L	GPRS/MMS/3G Samsung SGH-C420L	GPRS/MMS/3G Samsung SGHC420L
Samsung	SGH-C421	GPRS/MMS/3G Samsung SGH-C421	GPRS/MMS/3G Samsung SGHC421
Samsung	SGH-C425	GPRS/MMS/3G Samsung SGH-C425	GPRS/MMS/3G Samsung SGHC425
Samsung	SGH-C426	GPRS/MMS/3G Samsung SGH-C426	GPRS/MMS/3G Samsung SGHC426
Samsung	SGH-C428	GPRS/MMS/3G Samsung SGH-C428	GPRS/MMS/3G Samsung SGHC428
Samsung	SGH-C450	GPRS/MMS/3G Samsung SGH-C450	GPRS/MMS/3G Samsung SGHC450
Samsung	SGH-C458	GPRS/MMS/3G Samsung SGH-C458	GPRS/MMS/3G Samsung SGHC458
Samsung	SGH-C500	GPRS/MMS/3G Samsung SGH-C500	GPRS/MMS/3G Samsung SGHC500
Samsung	SGH-C500L	GPRS/MMS/3G Samsung SGH-C500L	GPRS/MMS/3G Samsung SGHC500L
Samsung	SGH-C506	GPRS/MMS/3G Samsung SGH-C506	GPRS/MMS/3G Samsung SGHC506
Samsung	SGH-C510	GPRS/MMS/3G Samsung SGH-C510	GPRS/MMS/3G Samsung SGHC510
Samsung	SGH-C510L	GPRS/MMS/3G Samsung SGH-C510L	GPRS/MMS/3G Samsung SGHC510L
Samsung	SGH-C510V	GPRS/MMS/3G Samsung SGH-C510V	GPRS/MMS/3G Samsung SGHC510V
Samsung	SGH-C516	GPRS/MMS/3G Samsung SGH-C516	GPRS/MMS/3G Samsung SGHC516
Samsung	SGH-C520	GPRS/MMS/3G Samsung SGH-C520	GPRS/MMS/3G Samsung SGHC520
Samsung	SGH-D100	GPRS/MMS/3G Samsung SGH-D100	GPRS/MMS/3G Samsung SGHD100
Samsung	SGH-D100A	GPRS/MMS/3G Samsung SGH-D100A	GPRS/MMS/3G Samsung SGHD100A
Samsung	SGH-D108	GPRS/MMS/3G Samsung SGH-D108	GPRS/MMS/3G Samsung SGHD108
Samsung	SGH-D300	GPRS/MMS/3G Samsung SGH-D300	GPRS/MMS/3G Samsung SGHD300
Samsung	SGH-D307	GPRS/MMS/3G Samsung SGH-D307	GPRS/MMS/3G Samsung SGHD307
Samsung	SGH-D347	GPRS/MMS/3G Samsung SGH-D347	GPRS/MMS/3G Samsung SGHD347
Samsung	SGH-D357	GPRS/MMS/3G Samsung SGH-D357	GPRS/MMS/3G Samsung SGHD357
Samsung	SGH-D407	GPRS/MMS/3G Samsung SGH-D407	GPRS/MMS/3G Samsung SGHD407
Samsung	SGH-D407T	GPRS/MMS/3G Samsung SGH-D407T	GPRS/MMS/3G Samsung SGHD407T
Samsung	SGH-D410	GPRS/MMS/3G Samsung SGH-D410	GPRS/MMS/3G Samsung SGHD410
Samsung	SGH-D410C	GPRS/MMS/3G Samsung SGH-D410C	GPRS/MMS/3G Samsung SGHD410C
Samsung	SGH-D418	GPRS/MMS/3G Samsung SGH-D418	GPRS/MMS/3G Samsung SGHD418
Samsung	SGH-D428	GPRS/MMS/3G Samsung SGH-D428	GPRS/MMS/3G Samsung SGHD428
Samsung	SGH-D488	GPRS/MMS/3G Samsung SGH-D488	GPRS/MMS/3G Samsung SGHD488

Samsung	SGH-D500	GPRS/MMS/3G Samsung SGH-D500	GPRS/MMS/3G Samsung SGHD500
Samsung	SGH-D500C	GPRS/MMS/3G Samsung SGH-D500C	GPRS/MMS/3G Samsung SGHD500C
Samsung	SGH-D500E	GPRS/MMS/3G Samsung SGH-D500E	GPRS/MMS/3G Samsung SGHD500E
Samsung	SGH-D508	GPRS/MMS/3G Samsung SGH-D508	GPRS/MMS/3G Samsung SGHD508
Samsung	SGH-D510	GPRS/MMS/3G Samsung SGH-D510	GPRS/MMS/3G Samsung SGHD510
Samsung	SGH-D510C	GPRS/MMS/3G Samsung SGH-D510C	GPRS/MMS/3G Samsung SGHD510C
Samsung	SGH-D520	GPRS/MMS/3G Samsung SGH-D520	GPRS/MMS/3G Samsung SGHD520
Samsung	SGH-D528	GPRS/MMS/3G Samsung SGH-D528	GPRS/MMS/3G Samsung SGHD528
Samsung	SGH-D600	GPRS/MMS/3G Samsung SGH-D600	GPRS/MMS/3G Samsung SGHD600
Samsung	SGH-D600E	GPRS/MMS/3G Samsung SGH-D600E	GPRS/MMS/3G Samsung SGHD600E
Samsung	SGH-D606	GPRS/MMS/3G Samsung SGH-D606	GPRS/MMS/3G Samsung SGHD606
Samsung	SGH-D608	GPRS/MMS/3G Samsung SGH-D608	GPRS/MMS/3G Samsung SGHD608
Samsung	SGH-D720	GPRS/MMS/3G Samsung SGH-D720	GPRS/MMS/3G Samsung SGHD720
Samsung	SGH-D728	GPRS/MMS/3G Samsung SGH-D728	GPRS/MMS/3G Samsung SGHD728
Samsung	SGH-D730	GPRS/MMS/3G Samsung SGH-D730	GPRS/MMS/3G Samsung SGHD730
Samsung	SGH-D738	GPRS/MMS/3G Samsung SGH-D738	GPRS/MMS/3G Samsung SGHD738
Samsung	SGH-D800	GPRS/MMS/3G Samsung SGH-D800	GPRS/MMS/3G Samsung SGHD800
Samsung	SGH-D806	GPRS/MMS/3G Samsung SGH-D806	GPRS/MMS/3G Samsung SGHD806
Samsung	SGH-D807	GPRS/MMS/3G Samsung SGH-D807	GPRS/MMS/3G Samsung SGHD807
Samsung	SGH-D808	GPRS/MMS/3G Samsung SGH-D808	GPRS/MMS/3G Samsung SGHD808
Samsung	SGH-D810	GPRS/MMS/3G Samsung SGH-D810	GPRS/MMS/3G Samsung SGHD810
Samsung	SGH-D820	GPRS/MMS/3G Samsung SGH-D820	GPRS/MMS/3G Samsung SGHD820
Samsung	SGH-D828+	GPRS/MMS/3G Samsung SGH-D828+	GPRS/MMS/3G Samsung SGHD828+
Samsung	SGH-D828	GPRS/MMS/3G Samsung SGH-D828	GPRS/MMS/3G Samsung SGHD828
Samsung	SGH-D828E	GPRS/MMS/3G Samsung SGH-D828E	GPRS/MMS/3G Samsung SGHD828E
Samsung	SGH-D830	GPRS/MMS/3G Samsung SGH-D830	GPRS/MMS/3G Samsung SGHD830
Samsung	SGH-D836	GPRS/MMS/3G Samsung SGH-D836	GPRS/MMS/3G Samsung SGHD836
Samsung	SGH-D838	GPRS/MMS/3G Samsung SGH-D838	GPRS/MMS/3G Samsung SGHD838
Samsung	SGH-D840	GPRS/MMS/3G Samsung SGH-D840	GPRS/MMS/3G Samsung SGHD840
Samsung	SGH-D848	GPRS/MMS/3G Samsung SGH-D848	GPRS/MMS/3G Samsung SGHD848
Samsung	SGH-D870	GPRS/MMS/3G Samsung SGH-D870	GPRS/MMS/3G Samsung SGHD870
Samsung	SGH-D900	GPRS/MMS/3G Samsung SGH-D900	GPRS/MMS/3G Samsung SGHD900
Samsung	SGH-D900i	GPRS/MMS/3G Samsung SGH-D900i	GPRS/MMS/3G Samsung SGHD900i
Samsung	SGH-D908	GPRS/MMS/3G Samsung SGH-D908	GPRS/MMS/3G Samsung SGHD908
Samsung	SGH-D908i	GPRS/MMS/3G Samsung SGH-D908i	GPRS/MMS/3G Samsung SGHD908i
Samsung	SGH-E100	GPRS/MMS/3G Samsung SGH-E100	GPRS/MMS/3G Samsung SGHE100
Samsung	SGH-E100A	GPRS/MMS/3G Samsung SGH-E100A	GPRS/MMS/3G Samsung SGHE100A
Samsung	SGH-E105	GPRS/MMS/3G Samsung SGH-E105	GPRS/MMS/3G Samsung SGHE105
Samsung	SGH-E108	GPRS/MMS/3G Samsung SGH-E108	GPRS/MMS/3G Samsung SGHE108
Samsung	SGH-E116	GPRS/MMS/3G Samsung SGH-E116	GPRS/MMS/3G Samsung SGHE116
Samsung	SGH-E200	GPRS/MMS/3G Samsung SGH-E200	GPRS/MMS/3G Samsung SGHE200
Samsung	SGH-E200B	GPRS/MMS/3G Samsung SGH-E200B	GPRS/MMS/3G Samsung SGHE200B
Samsung	SGH-E208	GPRS/MMS/3G Samsung SGH-E208	GPRS/MMS/3G Samsung SGHE208
Samsung	SGH-E208B	GPRS/MMS/3G Samsung SGH-E208B	GPRS/MMS/3G Samsung SGHE208B
Samsung	SGH-E210	GPRS/MMS/3G Samsung SGH-E210	GPRS/MMS/3G Samsung SGHE210
Samsung	SGH-E218	GPRS/MMS/3G Samsung SGH-E218	GPRS/MMS/3G Samsung SGHE218
Samsung	SGH-E230	GPRS/MMS/3G Samsung SGH-E230	GPRS/MMS/3G Samsung SGHE230
Samsung	SGH-E230L	GPRS/MMS/3G Samsung SGH-E230L	GPRS/MMS/3G Samsung SGHE230L
Samsung	SGH-E236	GPRS/MMS/3G Samsung SGH-E236	GPRS/MMS/3G Samsung SGHE236
Samsung	SGH-E250	GPRS/MMS/3G Samsung SGH-E250	GPRS/MMS/3G Samsung SGHE250
Samsung	SGH-E250V	GPRS/MMS/3G Samsung SGH-E250V	GPRS/MMS/3G Samsung SGHE250V
Samsung	SGH-E256	GPRS/MMS/3G Samsung SGH-E256	GPRS/MMS/3G Samsung SGHE256
Samsung	SGH-E258	GPRS/MMS/3G Samsung SGH-E258	GPRS/MMS/3G Samsung SGHE258
Samsung	SGH-E300	GPRS/MMS/3G Samsung SGH-E300	GPRS/MMS/3G Samsung SGHE300
Samsung	SGH-E308	GPRS/MMS/3G Samsung SGH-E308	GPRS/MMS/3G Samsung SGHE308

Samsung	SGH-E310	GPRS/MMS/3G Samsung SGH-E310	GPRS/MMS/3G Samsung SGHE310
Samsung	SGH-E310C	GPRS/MMS/3G Samsung SGH-E310C	GPRS/MMS/3G Samsung SGHE310C
Samsung	SGH-E315	GPRS/MMS/3G Samsung SGH-E315	GPRS/MMS/3G Samsung SGHE315
Samsung	SGH-E316	GPRS/MMS/3G Samsung SGH-E316	GPRS/MMS/3G Samsung SGHE316
Samsung	SGH-E317	GPRS/MMS/3G Samsung SGH-E317	GPRS/MMS/3G Samsung SGHE317
Samsung	SGH-E318	GPRS/MMS/3G Samsung SGH-E318	GPRS/MMS/3G Samsung SGHE318
Samsung	SGH-E320	GPRS/MMS/3G Samsung SGH-E320	GPRS/MMS/3G Samsung SGHE320
Samsung	SGH-E330	GPRS/MMS/3G Samsung SGH-E330	GPRS/MMS/3G Samsung SGHE330
Samsung	SGH-E330C	GPRS/MMS/3G Samsung SGH-E330C	GPRS/MMS/3G Samsung SGHE330C
Samsung	SGH-E330N	GPRS/MMS/3G Samsung SGH-E330N	GPRS/MMS/3G Samsung SGHE330N
Samsung	SGH-E330S	GPRS/MMS/3G Samsung SGH-E330S	GPRS/MMS/3G Samsung SGHE330S
Samsung	SGH-E335	GPRS/MMS/3G Samsung SGH-E335	GPRS/MMS/3G Samsung SGHE335
Samsung	SGH-E338	GPRS/MMS/3G Samsung SGH-E338	GPRS/MMS/3G Samsung SGHE338
Samsung	SGH-E340	GPRS/MMS/3G Samsung SGH-E340	GPRS/MMS/3G Samsung SGHE340
Samsung	SGH-E340E	GPRS/MMS/3G Samsung SGH-E340E	GPRS/MMS/3G Samsung SGHE340E
Samsung	SGH-E348	GPRS/MMS/3G Samsung SGH-E348	GPRS/MMS/3G Samsung SGHE348
Samsung	SGH-E350	GPRS/MMS/3G Samsung SGH-E350	GPRS/MMS/3G Samsung SGHE350
Samsung	SGH-E350E	GPRS/MMS/3G Samsung SGH-E350E	GPRS/MMS/3G Samsung SGHE350E
Samsung	SGH-E351	GPRS/MMS/3G Samsung SGH-E351	GPRS/MMS/3G Samsung SGHE351
Samsung	SGH-E351L	GPRS/MMS/3G Samsung SGH-E351L	GPRS/MMS/3G Samsung SGHE351L
Samsung	SGH-E356	GPRS/MMS/3G Samsung SGH-E356	GPRS/MMS/3G Samsung SGHE356
Samsung	SGH-E358	GPRS/MMS/3G Samsung SGH-E358	GPRS/MMS/3G Samsung SGHE358
Samsung	SGH-E360	GPRS/MMS/3G Samsung SGH-E360	GPRS/MMS/3G Samsung SGHE360
Samsung	SGH-E360E	GPRS/MMS/3G Samsung SGH-E360E	GPRS/MMS/3G Samsung SGHE360E
Samsung	SGH-E368	GPRS/MMS/3G Samsung SGH-E368	GPRS/MMS/3G Samsung SGHE368
Samsung	SGH-E370	GPRS/MMS/3G Samsung SGH-E370	GPRS/MMS/3G Samsung SGHE370
Samsung	SGH-E376	GPRS/MMS/3G Samsung SGH-E376	GPRS/MMS/3G Samsung SGHE376
Samsung	SGH-E378	GPRS/MMS/3G Samsung SGH-E378	GPRS/MMS/3G Samsung SGHE378
Samsung	SGH-E380	GPRS/MMS/3G Samsung SGH-E380	GPRS/MMS/3G Samsung SGHE380
Samsung	SGH-E388	GPRS/MMS/3G Samsung SGH-E388	GPRS/MMS/3G Samsung SGHE388
Samsung	SGH-E390	GPRS/MMS/3G Samsung SGH-E390	GPRS/MMS/3G Samsung SGHE390
Samsung	SGH-E398	GPRS/MMS/3G Samsung SGH-E398	GPRS/MMS/3G Samsung SGHE398
Samsung	SGH-E400	GPRS/MMS/3G Samsung SGH-E400	GPRS/MMS/3G Samsung SGHE400
Samsung	SGH-E418	GPRS/MMS/3G Samsung SGH-E418	GPRS/MMS/3G Samsung SGHE418
Samsung	SGH-E420	GPRS/MMS/3G Samsung SGH-E420	GPRS/MMS/3G Samsung SGHE420
Samsung	SGH-E428	GPRS/MMS/3G Samsung SGH-E428	GPRS/MMS/3G Samsung SGHE428
Samsung	SGH-E480	GPRS/MMS/3G Samsung SGH-E480	GPRS/MMS/3G Samsung SGHE480
Samsung	SGH-E488	GPRS/MMS/3G Samsung SGH-E488	GPRS/MMS/3G Samsung SGHE488
Samsung	SGH-E490	GPRS/MMS/3G Samsung SGH-E490	GPRS/MMS/3G Samsung SGHE490
Samsung	SGH-E490L	GPRS/MMS/3G Samsung SGH-E490L	GPRS/MMS/3G Samsung SGHE490L
Samsung	SGH-E496	GPRS/MMS/3G Samsung SGH-E496	GPRS/MMS/3G Samsung SGHE496
Samsung	SGH-E496L	GPRS/MMS/3G Samsung SGH-E496L	GPRS/MMS/3G Samsung SGHE496L
Samsung	SGH-E498	GPRS/MMS/3G Samsung SGH-E498	GPRS/MMS/3G Samsung SGHE498
Samsung	SGH-E500	GPRS/MMS/3G Samsung SGH-E500	GPRS/MMS/3G Samsung SGHE500
Samsung	SGH-E500C	GPRS/MMS/3G Samsung SGH-E500C	GPRS/MMS/3G Samsung SGHE500C
Samsung	SGH-E510	GPRS/MMS/3G Samsung SGH-E510	GPRS/MMS/3G Samsung SGHE510
Samsung	SGH-E518	GPRS/MMS/3G Samsung SGH-E518	GPRS/MMS/3G Samsung SGHE518
Samsung	SGH-E530	GPRS/MMS/3G Samsung SGH-E530	GPRS/MMS/3G Samsung SGHE530
Samsung	SGH-E530C	GPRS/MMS/3G Samsung SGH-E530C	GPRS/MMS/3G Samsung SGHE530C
Samsung	SGH-E538	GPRS/MMS/3G Samsung SGH-E538	GPRS/MMS/3G Samsung SGHE538
Samsung	SGH-E550	GPRS/MMS/3G Samsung SGH-E550	GPRS/MMS/3G Samsung SGHE550
Samsung	SGH-E568	GPRS/MMS/3G Samsung SGH-E568	GPRS/MMS/3G Samsung SGHE568
Samsung	SGH-E570	GPRS/MMS/3G Samsung SGH-E570	GPRS/MMS/3G Samsung SGHE570
Samsung	SGH-E570L	GPRS/MMS/3G Samsung SGH-E570L	GPRS/MMS/3G Samsung SGHE570L
Samsung	SGH-E570V	GPRS/MMS/3G Samsung SGH-E570V	GPRS/MMS/3G Samsung SGHE570V

Samsung	SGH-E576	GPRS/MMS/3G Samsung SGH-E576	GPRS/MMS/3G Samsung SGHE576
Samsung	SGH-E578	GPRS/MMS/3G Samsung SGH-E578	GPRS/MMS/3G Samsung SGHE578
Samsung	SGH-E590	GPRS/MMS/3G Samsung SGH-E590	GPRS/MMS/3G Samsung SGHE590
Samsung	SGH-E598	GPRS/MMS/3G Samsung SGH-E598	GPRS/MMS/3G Samsung SGHE598
Samsung	SGH-E600	GPRS/MMS/3G Samsung SGH-E600	GPRS/MMS/3G Samsung SGHE600
Samsung	SGH-E600C	GPRS/MMS/3G Samsung SGH-E600C	GPRS/MMS/3G Samsung SGHE600C
Samsung	SGH-E608	GPRS/MMS/3G Samsung SGH-E608	GPRS/MMS/3G Samsung SGHE608
Samsung	SGH-E610	GPRS/MMS/3G Samsung SGH-E610	GPRS/MMS/3G Samsung SGHE610
Samsung	SGH-E610C	GPRS/MMS/3G Samsung SGH-E610C	GPRS/MMS/3G Samsung SGHE610C
Samsung	SGH-E618	GPRS/MMS/3G Samsung SGH-E618	GPRS/MMS/3G Samsung SGHE618
Samsung	SGH-E620	GPRS/MMS/3G Samsung SGH-E620	GPRS/MMS/3G Samsung SGHE620
Samsung	SGH-E620C	GPRS/MMS/3G Samsung SGH-E620C	GPRS/MMS/3G Samsung SGHE620C
Samsung	SGH-E628	GPRS/MMS/3G Samsung SGH-E628	GPRS/MMS/3G Samsung SGHE628
Samsung	SGH-E630	GPRS/MMS/3G Samsung SGH-E630	GPRS/MMS/3G Samsung SGHE630
Samsung	SGH-E630C	GPRS/MMS/3G Samsung SGH-E630C	GPRS/MMS/3G Samsung SGHE630C
Samsung	SGH-E630S	GPRS/MMS/3G Samsung SGH-E630S	GPRS/MMS/3G Samsung SGHE630S
Samsung	SGH-E635	GPRS/MMS/3G Samsung SGH-E635	GPRS/MMS/3G Samsung SGHE635
Samsung	SGH-E638	GPRS/MMS/3G Samsung SGH-E638	GPRS/MMS/3G Samsung SGHE638
Samsung	SGH-E640	GPRS/MMS/3G Samsung SGH-E640	GPRS/MMS/3G Samsung SGHE640
Samsung	SGH-E648	GPRS/MMS/3G Samsung SGH-E648	GPRS/MMS/3G Samsung SGHE648
Samsung	SGH-E690	GPRS/MMS/3G Samsung SGH-E690	GPRS/MMS/3G Samsung SGHE690
Samsung	SGH-E700	GPRS/MMS/3G Samsung SGH-E700	GPRS/MMS/3G Samsung SGHE700
Samsung	SGH-E700A	GPRS/MMS/3G Samsung SGH-E700A	GPRS/MMS/3G Samsung SGHE700A
Samsung	SGH-E708	GPRS/MMS/3G Samsung SGH-E708	GPRS/MMS/3G Samsung SGHE708
Samsung	SGH-E710	GPRS/MMS/3G Samsung SGH-E710	GPRS/MMS/3G Samsung SGHE710
Samsung	SGH-E715	GPRS/MMS/3G Samsung SGH-E715	GPRS/MMS/3G Samsung SGHE715
Samsung	SGH-E720	GPRS/MMS/3G Samsung SGH-E720	GPRS/MMS/3G Samsung SGHE720
Samsung	SGH-E720C	GPRS/MMS/3G Samsung SGH-E720C	GPRS/MMS/3G Samsung SGHE720C
Samsung	SGH-E720i	GPRS/MMS/3G Samsung SGH-E720i	GPRS/MMS/3G Samsung SGHE720i
Samsung	SGH-E728	GPRS/MMS/3G Samsung SGH-E728	GPRS/MMS/3G Samsung SGHE728
Samsung	SGH-E730	GPRS/MMS/3G Samsung SGH-E730	GPRS/MMS/3G Samsung SGHE730
Samsung	SGH-E730E	GPRS/MMS/3G Samsung SGH-E730E	GPRS/MMS/3G Samsung SGHE730E
Samsung	SGH-E736	GPRS/MMS/3G Samsung SGH-E736	GPRS/MMS/3G Samsung SGHE736
Samsung	SGH-E738	GPRS/MMS/3G Samsung SGH-E738	GPRS/MMS/3G Samsung SGHE738
Samsung	SGH-E740	GPRS/MMS/3G Samsung SGH-E740	GPRS/MMS/3G Samsung SGHE740
Samsung	SGH-E746	GPRS/MMS/3G Samsung SGH-E746	GPRS/MMS/3G Samsung SGHE746
Samsung	SGH-E748	GPRS/MMS/3G Samsung SGH-E748	GPRS/MMS/3G Samsung SGHE748
Samsung	SGH-E750	GPRS/MMS/3G Samsung SGH-E750	GPRS/MMS/3G Samsung SGHE750
Samsung	SGH-E758	GPRS/MMS/3G Samsung SGH-E758	GPRS/MMS/3G Samsung SGHE758
Samsung	SGH-E760	GPRS/MMS/3G Samsung SGH-E760	GPRS/MMS/3G Samsung SGHE760
Samsung	SGH-E770	GPRS/MMS/3G Samsung SGH-E770	GPRS/MMS/3G Samsung SGHE770
Samsung	SGH-E778	GPRS/MMS/3G Samsung SGH-E778	GPRS/MMS/3G Samsung SGHE778
Samsung	SGH-E780	GPRS/MMS/3G Samsung SGH-E780	GPRS/MMS/3G Samsung SGHE780
Samsung	SGH-E786	GPRS/MMS/3G Samsung SGH-E786	GPRS/MMS/3G Samsung SGHE786
Samsung	SGH-E788+	GPRS/MMS/3G Samsung SGH-E788+	GPRS/MMS/3G Samsung SGHE788+
Samsung	SGH-E788	GPRS/MMS/3G Samsung SGH-E788	GPRS/MMS/3G Samsung SGHE788
Samsung	SGH-E788e	GPRS/MMS/3G Samsung SGH-E788e	GPRS/MMS/3G Samsung SGHE788e
Samsung	SGH-E790	GPRS/MMS/3G Samsung SGH-E790	GPRS/MMS/3G Samsung SGHE790
Samsung	SGH-E800	GPRS/MMS/3G Samsung SGH-E800	GPRS/MMS/3G Samsung SGHE800
Samsung	SGH-E800C	GPRS/MMS/3G Samsung SGH-E800C	GPRS/MMS/3G Samsung SGHE800C
Samsung	SGH-E800N	GPRS/MMS/3G Samsung SGH-E800N	GPRS/MMS/3G Samsung SGHE800N
Samsung	SGH-E808	GPRS/MMS/3G Samsung SGH-E808	GPRS/MMS/3G Samsung SGHE808
Samsung	SGH-E810	GPRS/MMS/3G Samsung SGH-E810	GPRS/MMS/3G Samsung SGHE810
Samsung	SGH-E810C	GPRS/MMS/3G Samsung SGH-E810C	GPRS/MMS/3G Samsung SGHE810C
Samsung	SGH-E818	GPRS/MMS/3G Samsung SGH-E818	GPRS/MMS/3G Samsung SGHE818

Samsung	SGH-E820	GPRS/MMS/3G Samsung SGH-E820	GPRS/MMS/3G Samsung SGHE820
Samsung	SGH-E820N	GPRS/MMS/3G Samsung SGH-E820N	GPRS/MMS/3G Samsung SGHE820N
Samsung	SGH-E820P	GPRS/MMS/3G Samsung SGH-E820P	GPRS/MMS/3G Samsung SGHE820P
Samsung	SGH-E820T	GPRS/MMS/3G Samsung SGH-E820T	GPRS/MMS/3G Samsung SGHE820T
Samsung	SGH-E830	GPRS/MMS/3G Samsung SGH-E830	GPRS/MMS/3G Samsung SGHE830
Samsung	SGH-E838	GPRS/MMS/3G Samsung SGH-E838	GPRS/MMS/3G Samsung SGHE838
Samsung	SGH-E840	GPRS/MMS/3G Samsung SGH-E840	GPRS/MMS/3G Samsung SGHE840
Samsung	SGH-E848	GPRS/MMS/3G Samsung SGH-E848	GPRS/MMS/3G Samsung SGHE848
Samsung	SGH-E850	GPRS/MMS/3G Samsung SGH-E850	GPRS/MMS/3G Samsung SGHE850
Samsung	SGH-E870	GPRS/MMS/3G Samsung SGH-E870	GPRS/MMS/3G Samsung SGHE870
Samsung	SGH-E878	GPRS/MMS/3G Samsung SGH-E878	GPRS/MMS/3G Samsung SGHE878
Samsung	SGH-E880	GPRS/MMS/3G Samsung SGH-E880	GPRS/MMS/3G Samsung SGHE880
Samsung	SGH-E888	GPRS/MMS/3G Samsung SGH-E888	GPRS/MMS/3G Samsung SGHE888
Samsung	SGH-E890	GPRS/MMS/3G Samsung SGH-E890	GPRS/MMS/3G Samsung SGHE890
Samsung	SGH-E898	GPRS/MMS/3G Samsung SGH-E898	GPRS/MMS/3G Samsung SGHE898
Samsung	SGH-E900	GPRS/MMS/3G Samsung SGH-E900	GPRS/MMS/3G Samsung SGHE900
Samsung	SGH-E900i	GPRS/MMS/3G Samsung SGH-E900i	GPRS/MMS/3G Samsung SGHE900i
Samsung	SGH-E906	GPRS/MMS/3G Samsung SGH-E906	GPRS/MMS/3G Samsung SGHE906
Samsung	SGH-E908	GPRS/MMS/3G Samsung SGH-E908	GPRS/MMS/3G Samsung SGHE908
Samsung	SGH-E910	GPRS/MMS/3G Samsung SGH-E910	GPRS/MMS/3G Samsung SGHE910
Samsung	SGH-E918	GPRS/MMS/3G Samsung SGH-E918	GPRS/MMS/3G Samsung SGHE918
Samsung	SGH-E950	GPRS/MMS/3G Samsung SGH-E950	GPRS/MMS/3G Samsung SGHE950
Samsung	SGH-E958	GPRS/MMS/3G Samsung SGH-E958	GPRS/MMS/3G Samsung SGHE958
Samsung	SGH-F200	GPRS/MMS/3G Samsung SGH-F200	GPRS/MMS/3G Samsung SGHF200
Samsung	SGH-F210	GPRS/MMS/3G Samsung SGH-F210	GPRS/MMS/3G Samsung SGHF210
Samsung	SGH-F218	GPRS/MMS/3G Samsung SGH-F218	GPRS/MMS/3G Samsung SGHF218
Samsung	SGH-F300	GPRS/MMS/3G Samsung SGH-F300	GPRS/MMS/3G Samsung SGHF300
Samsung	SGH-F300N	GPRS/MMS/3G Samsung SGH-F300N	GPRS/MMS/3G Samsung SGHF300N
Samsung	SGH-F308	GPRS/MMS/3G Samsung SGH-F308	GPRS/MMS/3G Samsung SGHF308
Samsung	SGH-F330	GPRS/MMS/3G Samsung SGH-F330	GPRS/MMS/3G Samsung SGHF330
Samsung	SGH-F500	GPRS/MMS/3G Samsung SGH-F500	GPRS/MMS/3G Samsung SGHF500
Samsung	SGH-F508	GPRS/MMS/3G Samsung SGH-F508	GPRS/MMS/3G Samsung SGHF508
Samsung	SGH-F520	GPRS/MMS/3G Samsung SGH-F520	GPRS/MMS/3G Samsung SGHF520
Samsung	SGH-F700	GPRS/MMS/3G Samsung SGH-F700	GPRS/MMS/3G Samsung SGHF700
Samsung	SGH-F700V	GPRS/MMS/3G Samsung SGH-F700V	GPRS/MMS/3G Samsung SGHF700V
Samsung	SGH-G600	GPRS/MMS/3G Samsung SGH-G600	GPRS/MMS/3G Samsung SGHG600
Samsung	SGH-G600V	GPRS/MMS/3G Samsung SGH-G600V	GPRS/MMS/3G Samsung SGHG600V
Samsung	SGH-G608	GPRS/MMS/3G Samsung SGH-G608	GPRS/MMS/3G Samsung SGHG608
Samsung	SGH-G800	GPRS/MMS/3G Samsung SGH-G800	GPRS/MMS/3G Samsung SGHG800
Samsung	SGH-i308	GPRS/MMS/3G Samsung SGH-i308	GPRS/MMS/3G Samsung SGHi308
Samsung	SGH-i400	GPRS/MMS/3G Samsung SGH-i400	GPRS/MMS/3G Samsung SGHi400
Samsung	SGH-i408	GPRS/MMS/3G Samsung SGH-i408	GPRS/MMS/3G Samsung SGHi408
Samsung	SGH-i450	GPRS/MMS/3G Samsung SGH-i450	GPRS/MMS/3G Samsung SGHi450
Samsung	SGH-i450V	GPRS/MMS/3G Samsung SGH-i450V	GPRS/MMS/3G Samsung SGHi450V
Samsung	SGH-i520	GPRS/MMS/3G Samsung SGH-i520	GPRS/MMS/3G Samsung SGHi520
Samsung	SGH-i550	GPRS/MMS/3G Samsung SGH-i550	GPRS/MMS/3G Samsung SGHi550
Samsung	SGH-i560	GPRS/MMS/3G Samsung SGH-i560	GPRS/MMS/3G Samsung SGHi560
Samsung	SGH-J200	GPRS/MMS/3G Samsung SGH-J200	GPRS/MMS/3G Samsung SGHJ200
Samsung	SGH-J600	GPRS/MMS/3G Samsung SGH-J600	GPRS/MMS/3G Samsung SGHJ600
Samsung	SGH-J600E	GPRS/MMS/3G Samsung SGH-J600E	GPRS/MMS/3G Samsung SGHJ600E
Samsung	SGH-J600V	GPRS/MMS/3G Samsung SGH-J600V	GPRS/MMS/3G Samsung SGHJ600V
Samsung	SGH-J608	GPRS/MMS/3G Samsung SGH-J608	GPRS/MMS/3G Samsung SGHJ608
Samsung	SGH-J750	GPRS/MMS/3G Samsung SGH-J750	GPRS/MMS/3G Samsung SGHJ750
Samsung	SGH-L600	GPRS/MMS/3G Samsung SGH-L600	GPRS/MMS/3G Samsung SGHL600
Samsung	SGH-L608	GPRS/MMS/3G Samsung SGH-L608	GPRS/MMS/3G Samsung SGHL608

Samsung	SGH-L760	GPRS/MMS/3G Samsung SGH-L760	GPRS/MMS/3G Samsung SGHL760
Samsung	SGH-L760S	GPRS/MMS/3G Samsung SGH-L760S	GPRS/MMS/3G Samsung SGHL760S
Samsung	SGH-L760V	GPRS/MMS/3G Samsung SGH-L760V	GPRS/MMS/3G Samsung SGHL760V
Samsung	SGH-L768	GPRS/MMS/3G Samsung SGH-L768	GPRS/MMS/3G Samsung SGHL768
Samsung	SGH-M300	GPRS/MMS/3G Samsung SGH-M300	GPRS/MMS/3G Samsung SGHM300
Samsung	SGH-M300V	GPRS/MMS/3G Samsung SGH-M300V	GPRS/MMS/3G Samsung SGHM300V
Samsung	SGH-M600	GPRS/MMS/3G Samsung SGH-M600	GPRS/MMS/3G Samsung SGHM600
Samsung	SGH-M610	GPRS/MMS/3G Samsung SGH-M610	GPRS/MMS/3G Samsung SGHM610
Samsung	SGH-N620	GPRS/MMS/3G Samsung SGH-N620	GPRS/MMS/3G Samsung SGHN620
Samsung	SGH-N620E	GPRS/MMS/3G Samsung SGH-N620E	GPRS/MMS/3G Samsung SGHN620E
Samsung	SGH-N625	GPRS/MMS/3G Samsung SGH-N625	GPRS/MMS/3G Samsung SGHN625
Samsung	SGH-N628	GPRS/MMS/3G Samsung SGH-N628	GPRS/MMS/3G Samsung SGHN628
Samsung	SGH-N628E	GPRS/MMS/3G Samsung SGH-N628E	GPRS/MMS/3G Samsung SGHN628E
Samsung	SGH-N700	GPRS/MMS/3G Samsung SGH-N700	GPRS/MMS/3G Samsung SGHN700
Samsung	SGH-P100	GPRS/MMS/3G Samsung SGH-P100	GPRS/MMS/3G Samsung SGHP100
Samsung	SGH-P107	GPRS/MMS/3G Samsung SGH-P107	GPRS/MMS/3G Samsung SGHP107
Samsung	SGH-P108	GPRS/MMS/3G Samsung SGH-P108	GPRS/MMS/3G Samsung SGHP108
Samsung	SGH-P110	GPRS/MMS/3G Samsung SGH-P110	GPRS/MMS/3G Samsung SGHP110
Samsung	SGH-P110V	GPRS/MMS/3G Samsung SGH-P110V	GPRS/MMS/3G Samsung SGHP110V
Samsung	SGH-P200	GPRS/MMS/3G Samsung SGH-P200	GPRS/MMS/3G Samsung SGHP200
Samsung	SGH-P207	GPRS/MMS/3G Samsung SGH-P207	GPRS/MMS/3G Samsung SGHP207
Samsung	SGH-P260	GPRS/MMS/3G Samsung SGH-P260	GPRS/MMS/3G Samsung SGHP260
Samsung	SGH-P300	GPRS/MMS/3G Samsung SGH-P300	GPRS/MMS/3G Samsung SGHP300
Samsung	SGH-P308	GPRS/MMS/3G Samsung SGH-P308	GPRS/MMS/3G Samsung SGHP308
Samsung	SGH-P310	GPRS/MMS/3G Samsung SGH-P310	GPRS/MMS/3G Samsung SGHP310
Samsung	SGH-P318	GPRS/MMS/3G Samsung SGH-P318	GPRS/MMS/3G Samsung SGHP318
Samsung	SGH-P400	GPRS/MMS/3G Samsung SGH-P400	GPRS/MMS/3G Samsung SGHP400
Samsung	SGH-P408+	GPRS/MMS/3G Samsung SGH-P408+	GPRS/MMS/3G Samsung SGHP408+
Samsung	SGH-P408	GPRS/MMS/3G Samsung SGH-P408	GPRS/MMS/3G Samsung SGHP408
Samsung	SGH-P510	GPRS/MMS/3G Samsung SGH-P510	GPRS/MMS/3G Samsung SGHP510
Samsung	SGH-P518	GPRS/MMS/3G Samsung SGH-P518	GPRS/MMS/3G Samsung SGHP518
Samsung	SGH-P520	GPRS/MMS/3G Samsung SGH-P520	GPRS/MMS/3G Samsung SGHP520
Samsung	SGH-P700	GPRS/MMS/3G Samsung SGH-P700	GPRS/MMS/3G Samsung SGHP700
Samsung	SGH-P705	GPRS/MMS/3G Samsung SGH-P705	GPRS/MMS/3G Samsung SGHP705
Samsung	SGH-P710	GPRS/MMS/3G Samsung SGH-P710	GPRS/MMS/3G Samsung SGHP710
Samsung	SGH-P716	GPRS/MMS/3G Samsung SGH-P716	GPRS/MMS/3G Samsung SGHP716
Samsung	SGH-P730	GPRS/MMS/3G Samsung SGH-P730	GPRS/MMS/3G Samsung SGHP730
Samsung	SGH-P730C	GPRS/MMS/3G Samsung SGH-P730C	GPRS/MMS/3G Samsung SGHP730C
Samsung	SGH-P735	GPRS/MMS/3G Samsung SGH-P735	GPRS/MMS/3G Samsung SGHP735
Samsung	SGH-P738	GPRS/MMS/3G Samsung SGH-P738	GPRS/MMS/3G Samsung SGHP738
Samsung	SGH-P777	GPRS/MMS/3G Samsung SGH-P777	GPRS/MMS/3G Samsung SGHP777
Samsung	SGH-P850	GPRS/MMS/3G Samsung SGH-P850	GPRS/MMS/3G Samsung SGHP850
Samsung	SGH-P850C	GPRS/MMS/3G Samsung SGH-P850C	GPRS/MMS/3G Samsung SGHP850C
Samsung	SGH-P850S	GPRS/MMS/3G Samsung SGH-P850S	GPRS/MMS/3G Samsung SGHP850S
Samsung	SGH-P858	GPRS/MMS/3G Samsung SGH-P858	GPRS/MMS/3G Samsung SGHP858
Samsung	SGH-P900	GPRS/MMS/3G Samsung SGH-P900	GPRS/MMS/3G Samsung SGHP900
Samsung	SGH-P906	GPRS/MMS/3G Samsung SGH-P906	GPRS/MMS/3G Samsung SGHP906
Samsung	SGH-P908T	GPRS/MMS/3G Samsung SGH-P908T	GPRS/MMS/3G Samsung SGHP908T
Samsung	SGH-P910	GPRS/MMS/3G Samsung SGH-P910	GPRS/MMS/3G Samsung SGHP910
Samsung	SGH-P920	GPRS/MMS/3G Samsung SGH-P920	GPRS/MMS/3G Samsung SGHP920
Samsung	SGH-P930	GPRS/MMS/3G Samsung SGH-P930	GPRS/MMS/3G Samsung SGHP930
Samsung	SGH-P940	GPRS/MMS/3G Samsung SGH-P940	GPRS/MMS/3G Samsung SGHP940
Samsung	SGH-R200S	GPRS/MMS/3G Samsung SGH-R200S	GPRS/MMS/3G Samsung SGHR200S
Samsung	SGH-S300m	GPRS/MMS/3G Samsung SGH-S300m	GPRS/MMS/3G Samsung SGHS300m
Samsung	SGH-S400i	GPRS/MMS/3G Samsung SGH-S400i	GPRS/MMS/3G Samsung SGHS400i

Samsung	SGH-S720i	GPRS/MMS/3G Samsung SGH-S720i	GPRS/MMS/3G Samsung SGHS720i
Samsung	SGH-S730i	GPRS/MMS/3G Samsung SGH-S730i	GPRS/MMS/3G Samsung SGHS730i
Samsung	SGH-T209	GPRS/MMS/3G Samsung SGH-T209	GPRS/MMS/3G Samsung SGHT209
Samsung	SGH-T219	GPRS/MMS/3G Samsung SGH-T219	GPRS/MMS/3G Samsung SGHT219
Samsung	SGH-T309	GPRS/MMS/3G Samsung SGH-T309	GPRS/MMS/3G Samsung SGHT309
Samsung	SGH-T309H	GPRS/MMS/3G Samsung SGH-T309H	GPRS/MMS/3G Samsung SGHT309H
Samsung	SGH-T319	GPRS/MMS/3G Samsung SGH-T319	GPRS/MMS/3G Samsung SGHT319
Samsung	SGH-T329	GPRS/MMS/3G Samsung SGH-T329	GPRS/MMS/3G Samsung SGHT329
Samsung	SGH-T329S	GPRS/MMS/3G Samsung SGH-T329S	GPRS/MMS/3G Samsung SGHT329S
Samsung	SGH-T409	GPRS/MMS/3G Samsung SGH-T409	GPRS/MMS/3G Samsung SGHT409
Samsung	SGH-T419	GPRS/MMS/3G Samsung SGH-T419	GPRS/MMS/3G Samsung SGHT419
Samsung	SGH-T429	GPRS/MMS/3G Samsung SGH-T429	GPRS/MMS/3G Samsung SGHT429
Samsung	SGH-T509	GPRS/MMS/3G Samsung SGH-T509	GPRS/MMS/3G Samsung SGHT509
Samsung	SGH-T509S	GPRS/MMS/3G Samsung SGH-T509S	GPRS/MMS/3G Samsung SGHT509S
Samsung	SGH-T519	GPRS/MMS/3G Samsung SGH-T519	GPRS/MMS/3G Samsung SGHT519
Samsung	SGH-T539	GPRS/MMS/3G Samsung SGH-T539	GPRS/MMS/3G Samsung SGHT539
Samsung	SGH-T609	GPRS/MMS/3G Samsung SGH-T609	GPRS/MMS/3G Samsung SGHT609
Samsung	SGH-T619	GPRS/MMS/3G Samsung SGH-T619	GPRS/MMS/3G Samsung SGHT619
Samsung	SGH-T629	GPRS/MMS/3G Samsung SGH-T629	GPRS/MMS/3G Samsung SGHT629
Samsung	SGH-T639	GPRS/MMS/3G Samsung SGH-T639	GPRS/MMS/3G Samsung SGHT639
Samsung	SGH-T709	GPRS/MMS/3G Samsung SGH-T709	GPRS/MMS/3G Samsung SGHT709
Samsung	SGH-T719	GPRS/MMS/3G Samsung SGH-T719	GPRS/MMS/3G Samsung SGHT719
Samsung	SGH-T729	GPRS/MMS/3G Samsung SGH-T729	GPRS/MMS/3G Samsung SGHT729
Samsung	SGH-T809	GPRS/MMS/3G Samsung SGH-T809	GPRS/MMS/3G Samsung SGHT809
Samsung	SGH-U100	GPRS/MMS/3G Samsung SGH-U100	GPRS/MMS/3G Samsung SGHU100
Samsung	SGH-U106	GPRS/MMS/3G Samsung SGH-U106	GPRS/MMS/3G Samsung SGHU106
Samsung	SGH-U108	GPRS/MMS/3G Samsung SGH-U108	GPRS/MMS/3G Samsung SGHU108
Samsung	SGH-U300	GPRS/MMS/3G Samsung SGH-U300	GPRS/MMS/3G Samsung SGHU300
Samsung	SGH-U308	GPRS/MMS/3G Samsung SGH-U308	GPRS/MMS/3G Samsung SGHU308
Samsung	SGH-U600	GPRS/MMS/3G Samsung SGH-U600	GPRS/MMS/3G Samsung SGHU600
Samsung	SGH-U608	GPRS/MMS/3G Samsung SGH-U608	GPRS/MMS/3G Samsung SGHU608
Samsung	SGH-U700	GPRS/MMS/3G Samsung SGH-U700	GPRS/MMS/3G Samsung SGHU700
Samsung	SGH-U700V	GPRS/MMS/3G Samsung SGH-U700V	GPRS/MMS/3G Samsung SGHU700V
Samsung	SGH-U708	GPRS/MMS/3G Samsung SGH-U708	GPRS/MMS/3G Samsung SGHU708
Samsung	SGH-V200	GPRS/MMS/3G Samsung SGH-V200	GPRS/MMS/3G Samsung SGHV200
Samsung	SGH-V200C	GPRS/MMS/3G Samsung SGH-V200C	GPRS/MMS/3G Samsung SGHV200C
Samsung	SGH-V205	GPRS/MMS/3G Samsung SGH-V205	GPRS/MMS/3G Samsung SGHV205
Samsung	SGH-V206	GPRS/MMS/3G Samsung SGH-V206	GPRS/MMS/3G Samsung SGHV206
Samsung	SGH-V208	GPRS/MMS/3G Samsung SGH-V208	GPRS/MMS/3G Samsung SGHV208
Samsung	SGH-V804	GPRS/MMS/3G Samsung SGH-V804	GPRS/MMS/3G Samsung SGHV804
Samsung	SGH-X100	GPRS/MMS/3G Samsung SGH-X100	GPRS/MMS/3G Samsung SGHX100
Samsung	SGH-X100A	GPRS/MMS/3G Samsung SGH-X100A	GPRS/MMS/3G Samsung SGHX100A
Samsung	SGH-X105	GPRS/MMS/3G Samsung SGH-X105	GPRS/MMS/3G Samsung SGHX105
Samsung	SGH-X108	GPRS/MMS/3G Samsung SGH-X108	GPRS/MMS/3G Samsung SGHX108
Samsung	SGH-X120	GPRS/MMS/3G Samsung SGH-X120	GPRS/MMS/3G Samsung SGHX120
Samsung	SGH-X138	GPRS/MMS/3G Samsung SGH-X138	GPRS/MMS/3G Samsung SGHX138
Samsung	SGH-X140	GPRS/MMS/3G Samsung SGH-X140	GPRS/MMS/3G Samsung SGHX140
Samsung	SGH-X148	GPRS/MMS/3G Samsung SGH-X148	GPRS/MMS/3G Samsung SGHX148
Samsung	SGH-X160	GPRS/MMS/3G Samsung SGH-X160	GPRS/MMS/3G Samsung SGHX160
Samsung	SGH-X160L	GPRS/MMS/3G Samsung SGH-X160L	GPRS/MMS/3G Samsung SGHX160L
Samsung	SGH-X166	GPRS/MMS/3G Samsung SGH-X166	GPRS/MMS/3G Samsung SGHX166
Samsung	SGH-X168	GPRS/MMS/3G Samsung SGH-X168	GPRS/MMS/3G Samsung SGHX168
Samsung	SGH-X200	GPRS/MMS/3G Samsung SGH-X200	GPRS/MMS/3G Samsung SGHX200
Samsung	SGH-X208	GPRS/MMS/3G Samsung SGH-X208	GPRS/MMS/3G Samsung SGHX208
Samsung	SGH-X210	GPRS/MMS/3G Samsung SGH-X210	GPRS/MMS/3G Samsung SGHX210

Samsung	SGH-X218	GPRS/MMS/3G Samsung SGH-X218	GPRS/MMS/3G Samsung SGHX218
Samsung	SGH-X300	GPRS/MMS/3G Samsung SGH-X300	GPRS/MMS/3G Samsung SGHX300
Samsung	SGH-X308	GPRS/MMS/3G Samsung SGH-X308	GPRS/MMS/3G Samsung SGHX308
Samsung	SGH-X400	GPRS/MMS/3G Samsung SGH-X400	GPRS/MMS/3G Samsung SGHX400
Samsung	SGH-X426	GPRS/MMS/3G Samsung SGH-X426	GPRS/MMS/3G Samsung SGHX426
Samsung	SGH-X426M	GPRS/MMS/3G Samsung SGH-X426M	GPRS/MMS/3G Samsung SGHX426M
Samsung	SGH-X427	GPRS/MMS/3G Samsung SGH-X427	GPRS/MMS/3G Samsung SGHX427
Samsung	SGH-X427M	GPRS/MMS/3G Samsung SGH-X427M	GPRS/MMS/3G Samsung SGHX427M
Samsung	SGH-X430	GPRS/MMS/3G Samsung SGH-X430	GPRS/MMS/3G Samsung SGHX430
Samsung	SGH-X450	GPRS/MMS/3G Samsung SGH-X450	GPRS/MMS/3G Samsung SGHX450
Samsung	SGH-X458	GPRS/MMS/3G Samsung SGH-X458	GPRS/MMS/3G Samsung SGHX458
Samsung	SGH-X460	GPRS/MMS/3G Samsung SGH-X460	GPRS/MMS/3G Samsung SGHX460
Samsung	SGH-X460C	GPRS/MMS/3G Samsung SGH-X460C	GPRS/MMS/3G Samsung SGHX460C
Samsung	SGH-X461	GPRS/MMS/3G Samsung SGH-X461	GPRS/MMS/3G Samsung SGHX461
Samsung	SGH-X461L	GPRS/MMS/3G Samsung SGH-X461L	GPRS/MMS/3G Samsung SGHX461L
Samsung	SGH-X466	GPRS/MMS/3G Samsung SGH-X466	GPRS/MMS/3G Samsung SGHX466
Samsung	SGH-X467	GPRS/MMS/3G Samsung SGH-X467	GPRS/MMS/3G Samsung SGHX467
Samsung	SGH-X468+	GPRS/MMS/3G Samsung SGH-X468+	GPRS/MMS/3G Samsung SGHX468+
Samsung	SGH-X468	GPRS/MMS/3G Samsung SGH-X468	GPRS/MMS/3G Samsung SGHX468
Samsung	SGH-X475	GPRS/MMS/3G Samsung SGH-X475	GPRS/MMS/3G Samsung SGHX475
Samsung	SGH-X478	GPRS/MMS/3G Samsung SGH-X478	GPRS/MMS/3G Samsung SGHX478
Samsung	SGH-X480	GPRS/MMS/3G Samsung SGH-X480	GPRS/MMS/3G Samsung SGHX478
Samsung	SGH-X480C	GPRS/MMS/3G Samsung SGH-X480C	GPRS/MMS/3G Samsung SGHX480C
Samsung	SGH-X480L	GPRS/MMS/3G Samsung SGH-X480L	GPRS/MMS/3G Samsung SGHX480L
Samsung	SGH-X481	GPRS/MMS/3G Samsung SGH-X481	GPRS/MMS/3G Samsung SGHX481
Samsung	SGH-X486	GPRS/MMS/3G Samsung SGH-X486	GPRS/MMS/3G Samsung SGHX486
Samsung	SGH-X488	GPRS/MMS/3G Samsung SGH-X488	GPRS/MMS/3G Samsung SGHX488
Samsung	SGH-X490	GPRS/MMS/3G Samsung SGH-X490	GPRS/MMS/3G Samsung SGHX490
Samsung	SGH-X495	GPRS/MMS/3G Samsung SGH-X495	GPRS/MMS/3G Samsung SGHX495
Samsung	SGH-X495H	GPRS/MMS/3G Samsung SGH-X495H	GPRS/MMS/3G Samsung SGHX495H
Samsung	SGH-X496	GPRS/MMS/3G Samsung SGH-X496	GPRS/MMS/3G Samsung SGHX496
Samsung	SGH-X497	GPRS/MMS/3G Samsung SGH-X497	GPRS/MMS/3G Samsung SGHX497
Samsung	SGH-X500	GPRS/MMS/3G Samsung SGH-X500	GPRS/MMS/3G Samsung SGHX500
Samsung	SGH-X506	GPRS/MMS/3G Samsung SGH-X506	GPRS/MMS/3G Samsung SGHX506
Samsung	SGH-X507	GPRS/MMS/3G Samsung SGH-X507	GPRS/MMS/3G Samsung SGHX507
Samsung	SGH-X508	GPRS/MMS/3G Samsung SGH-X508	GPRS/MMS/3G Samsung SGHX508
Samsung	SGH-X510	GPRS/MMS/3G Samsung SGH-X510	GPRS/MMS/3G Samsung SGHX510
Samsung	SGH-X510V	GPRS/MMS/3G Samsung SGH-X510V	GPRS/MMS/3G Samsung SGHX510V
Samsung	SGH-X518	GPRS/MMS/3G Samsung SGH-X518	GPRS/MMS/3G Samsung GHX518
Samsung	SGH-X520	GPRS/MMS/3G Samsung SGH-X520	GPRS/MMS/3G Samsung SGHX520
Samsung	SGH-X526	GPRS/MMS/3G Samsung SGH-X526	GPRS/MMS/3G Samsung SGHX526
Samsung	SGH-X530	GPRS/MMS/3G Samsung SGH-X530	GPRS/MMS/3G Samsung SGHX530
Samsung	SGH-X540	GPRS/MMS/3G Samsung SGH-X540	GPRS/MMS/3G Samsung SGHX540
Samsung	SGH-X550	GPRS/MMS/3G Samsung SGH-X550	GPRS/MMS/3G Samsung SGHX550
Samsung	SGH-X560	GPRS/MMS/3G Samsung SGH-X560	GPRS/MMS/3G Samsung SGHX560
Samsung	SGH-X560L	GPRS/MMS/3G Samsung SGH-X560L	GPRS/MMS/3G Samsung SGHX560L
Samsung	SGH-X566	GPRS/MMS/3G Samsung SGH-X566	GPRS/MMS/3G Samsung SGHX566
Samsung	SGH-X568	GPRS/MMS/3G Samsung SGH-X568	GPRS/MMS/3G Samsung SGHX568
Samsung	SGH-X600	GPRS/MMS/3G Samsung SGH-X600	GPRS/MMS/3G Samsung SGHX600
Samsung	SGH-X600A	GPRS/MMS/3G Samsung SGH-X600A	GPRS/MMS/3G Samsung SGHX600A
Samsung	SGH-X608	GPRS/MMS/3G Samsung SGH-X608	GPRS/MMS/3G Samsung SGHX608
Samsung	SGH-X610	GPRS/MMS/3G Samsung SGH-X610	GPRS/MMS/3G Samsung SGHX610
Samsung	SGH-X620	GPRS/MMS/3G Samsung SGH-X620	GPRS/MMS/3G Samsung SGHX620
Samsung	SGH-X628	GPRS/MMS/3G Samsung SGH-X628	GPRS/MMS/3G Samsung SGHX628
Samsung	SGH-X630	GPRS/MMS/3G Samsung SGH-X630	GPRS/MMS/3G Samsung SGHX630

Samsung	SGH-X636	GPRS/MMS/3G Samsung SGH-X636	GPRS/MMS/3G Samsung SGHX636
Samsung	SGH-X638	GPRS/MMS/3G Samsung SGH-X638	GPRS/MMS/3G Samsung SGHX638
Samsung	SGH-X640	GPRS/MMS/3G Samsung SGH-X640	GPRS/MMS/3G Samsung SGHX640
Samsung	SGH-X640C	GPRS/MMS/3G Samsung SGH-X640C	GPRS/MMS/3G Samsung SGHX640C
Samsung	SGH-X640S	GPRS/MMS/3G Samsung SGH-X640S	GPRS/MMS/3G Samsung SGHX640S
Samsung	SGH-X648	GPRS/MMS/3G Samsung SGH-X648	GPRS/MMS/3G Samsung SGHX648
Samsung	SGH-X650	GPRS/MMS/3G Samsung SGH-X650	GPRS/MMS/3G Samsung SGHX650
Samsung	SGH-X656	GPRS/MMS/3G Samsung SGH-X656	GPRS/MMS/3G Samsung SGHX656
Samsung	SGH-X658	GPRS/MMS/3G Samsung SGH-X658	GPRS/MMS/3G Samsung SGHX658
Samsung	SGH-X660	GPRS/MMS/3G Samsung SGH-X660	GPRS/MMS/3G Samsung SGHX660
Samsung	SGH-X668	GPRS/MMS/3G Samsung SGH-X668	GPRS/MMS/3G Samsung SGHX668
Samsung	SGH-X670	GPRS/MMS/3G Samsung SGH-X670	GPRS/MMS/3G Samsung SGHX670
Samsung	SGH-X678	GPRS/MMS/3G Samsung SGH-X678	GPRS/MMS/3G Samsung SGHX678
Samsung	SGH-X680	GPRS/MMS/3G Samsung SGH-X680	GPRS/MMS/3G Samsung SGHX680
Samsung	SGH-X680V	GPRS/MMS/3G Samsung SGH-X680V	GPRS/MMS/3G Samsung SGHX680V
Samsung	SGH-X686	GPRS/MMS/3G Samsung SGH-X686	GPRS/MMS/3G Samsung SGHX686
Samsung	SGH-X688	GPRS/MMS/3G Samsung SGH-X688	GPRS/MMS/3G Samsung SGHX688
Samsung	SGH-X700	GPRS/MMS/3G Samsung SGH-X700	GPRS/MMS/3G Samsung SGHX700
Samsung	SGH-X700N	GPRS/MMS/3G Samsung SGH-X700N	GPRS/MMS/3G Samsung SGHX700N
Samsung	SGH-X708	GPRS/MMS/3G Samsung SGH-X708	GPRS/MMS/3G Samsung SGHX708
Samsung	SGH-X710	GPRS/MMS/3G Samsung SGH-X710	GPRS/MMS/3G Samsung SGHX710
Samsung	SGH-X718	GPRS/MMS/3G Samsung SGH-X718	GPRS/MMS/3G Samsung SGHX718
Samsung	SGH-X800	GPRS/MMS/3G Samsung SGH-X800	GPRS/MMS/3G Samsung SGHX800
Samsung	SGH-X808	GPRS/MMS/3G Samsung SGH-X808	GPRS/MMS/3G Samsung SGHX808
Samsung	SGH-X810	GPRS/MMS/3G Samsung SGH-X810	GPRS/MMS/3G Samsung SGHX810
Samsung	SGH-X818	GPRS/MMS/3G Samsung SGH-X818	GPRS/MMS/3G Samsung SGHX818
Samsung	SGH-X820	GPRS/MMS/3G Samsung SGH-X820	GPRS/MMS/3G Samsung SGHX820
Samsung	SGH-X828	GPRS/MMS/3G Samsung SGH-X828	GPRS/MMS/3G Samsung SGHX828
Samsung	SGH-X830	GPRS/MMS/3G Samsung SGH-X830	GPRS/MMS/3G Samsung SGHX830
Samsung	SGH-X836	GPRS/MMS/3G Samsung SGH-X836	GPRS/MMS/3G Samsung SGHX836
Samsung	SGH-X838	GPRS/MMS/3G Samsung SGH-X838	GPRS/MMS/3G Samsung SGHX838
Samsung	SGH-Z100	GPRS/MMS/3G Samsung SGH-Z100	GPRS/MMS/3G Samsung SGHZ100
Samsung	SGH-Z105	GPRS/MMS/3G Samsung SGH-Z105	GPRS/MMS/3G Samsung SGHZ105
Samsung	SGH-Z105M	GPRS/MMS/3G Samsung SGH-Z105M	GPRS/MMS/3G Samsung SGHZ105M
Samsung	SGH-Z105T	GPRS/MMS/3G Samsung SGH-Z105T	GPRS/MMS/3G Samsung SGHZ105T
Samsung	SGH-Z105U	GPRS/MMS/3G Samsung SGH-Z105U	GPRS/MMS/3G Samsung SGHZ105U
Samsung	SGH-Z107	GPRS/MMS/3G Samsung SGH-Z107	GPRS/MMS/3G Samsung SGHZ107
Samsung	SGH-Z107M	GPRS/MMS/3G Samsung SGH-Z107M	GPRS/MMS/3G Samsung SGHZ107M
Samsung	SGH-Z107V	GPRS/MMS/3G Samsung SGH-Z107V	GPRS/MMS/3G Samsung SGHZ107V
Samsung	SGH-Z110	GPRS/MMS/3G Samsung SGH-Z110	GPRS/MMS/3G Samsung SGHZ110
Samsung	SGH-Z130	GPRS/MMS/3G Samsung SGH-Z130	GPRS/MMS/3G Samsung SGHZ130
Samsung	SGH-Z140	GPRS/MMS/3G Samsung SGH-Z140	GPRS/MMS/3G Samsung SGHZ140
Samsung	SGH-Z140M	GPRS/MMS/3G Samsung SGH-Z140M	GPRS/MMS/3G Samsung SGHZ140M
Samsung	SGH-Z140N	GPRS/MMS/3G Samsung SGH-Z140N	GPRS/MMS/3G Samsung SGHZ140N
Samsung	SGH-Z140V	GPRS/MMS/3G Samsung SGH-Z140V	GPRS/MMS/3G Samsung SGHZ140V
Samsung	SGH-Z150	GPRS/MMS/3G Samsung SGH-Z150	GPRS/MMS/3G Samsung SGHZ150
Samsung	SGH-Z170	GPRS/MMS/3G Samsung SGH-Z170	GPRS/MMS/3G Samsung SGHZ170
Samsung	SGH-Z220	GPRS/MMS/3G Samsung SGH-Z220	GPRS/MMS/3G Samsung SGHZ220
Samsung	SGH-Z230	GPRS/MMS/3G Samsung SGH-Z230	GPRS/MMS/3G Samsung SGHZ230
Samsung	SGH-Z238	GPRS/MMS/3G Samsung SGH-Z238	GPRS/MMS/3G Samsung SGHZ238
Samsung	SGH-Z240	GPRS/MMS/3G Samsung SGH-Z240	GPRS/MMS/3G Samsung SGHZ240
Samsung	SGH-Z240E	GPRS/MMS/3G Samsung SGH-Z240E	GPRS/MMS/3G Samsung SGHZ240E
Samsung	SGH-Z248	GPRS/MMS/3G Samsung SGH-Z248	GPRS/MMS/3G Samsung SGHZ248
Samsung	SGH-Z300	GPRS/MMS/3G Samsung SGH-Z300	GPRS/MMS/3G Samsung SGHZ300
Samsung	SGH-Z300M	GPRS/MMS/3G Samsung SGH-Z300M	GPRS/MMS/3G Samsung SGHZ300M

Samsung	SGH-Z308	GPRS/MMS/3G Samsung SGH-Z308	GPRS/MMS/3G Samsung SGHZ308
Samsung	SGH-Z310	GPRS/MMS/3G Samsung SGH-Z310	GPRS/MMS/3G Samsung SGHZ310
Samsung	SGH-Z320i	GPRS/MMS/3G Samsung SGH-Z320i	GPRS/MMS/3G Samsung SGHZ320i
Samsung	SGH-Z330	GPRS/MMS/3G Samsung SGH-Z330	GPRS/MMS/3G Samsung SGHZ330
Samsung	SGH-Z360	GPRS/MMS/3G Samsung SGH-Z360	GPRS/MMS/3G Samsung SGHZ360
Samsung	SGH-Z368	GPRS/MMS/3G Samsung SGH-Z368	GPRS/MMS/3G Samsung SGHZ368
Samsung	SGH-Z370	GPRS/MMS/3G Samsung SGH-Z370	GPRS/MMS/3G Samsung SGHZ370
Samsung	SGH-Z400	GPRS/MMS/3G Samsung SGH-Z400	GPRS/MMS/3G Samsung SGHZ400
Samsung	SGH-Z400V	GPRS/MMS/3G Samsung SGH-Z400V	GPRS/MMS/3G Samsung SGHZ400V
Samsung	SGH-Z500	GPRS/MMS/3G Samsung SGH-Z500	GPRS/MMS/3G Samsung SGHZ500
Samsung	SGH-Z508	GPRS/MMS/3G Samsung SGH-Z508	GPRS/MMS/3G Samsung SGHZ508
Samsung	SGH-Z510	GPRS/MMS/3G Samsung SGH-Z510	GPRS/MMS/3G Samsung SGHZ510
Samsung	SGH-Z520	GPRS/MMS/3G Samsung SGH-Z520	GPRS/MMS/3G Samsung SGHZ520
Samsung	SGH-Z540	GPRS/MMS/3G Samsung SGH-Z540	GPRS/MMS/3G Samsung SGHZ540
Samsung	SGH-Z540V	GPRS/MMS/3G Samsung SGH-Z540V	GPRS/MMS/3G Samsung SGHZ540V
Samsung	SGH-Z548	GPRS/MMS/3G Samsung SGH-Z548	GPRS/MMS/3G Samsung SGHZ548
Samsung	SGH-Z550	GPRS/MMS/3G Samsung SGH-Z550	GPRS/MMS/3G Samsung SGHZ550
Samsung	SGH-Z560	GPRS/MMS/3G Samsung SGH-Z560	GPRS/MMS/3G Samsung SGHZ560
Samsung	SGH-Z560V	GPRS/MMS/3G Samsung SGH-Z560V	GPRS/MMS/3G Samsung SGHZ560V
Samsung	SGH-Z600	GPRS/MMS/3G Samsung SGH-Z600	GPRS/MMS/3G Samsung SGHZ600
Samsung	SGH-Z620	GPRS/MMS/3G Samsung SGH-Z620	GPRS/MMS/3G Samsung SGHZ620
Samsung	SGH-Z630	GPRS/MMS/3G Samsung SGH-Z630	GPRS/MMS/3G Samsung SGHZ630
Samsung	SGH-Z710	GPRS/MMS/3G Samsung SGH-Z710	GPRS/MMS/3G Samsung SGHZ710
Samsung	SGH-Z720	GPRS/MMS/3G Samsung SGH-Z720	GPRS/MMS/3G Samsung SGHZ720
Samsung	SGH-Z720M	GPRS/MMS/3G Samsung SGH-Z720M	GPRS/MMS/3G Samsung SGHZ720M
Samsung	SGH-Z728	GPRS/MMS/3G Samsung SGH-Z728	GPRS/MMS/3G Samsung SGHZ728
Samsung	SGH-ZV10	GPRS/MMS/3G Samsung SGH-ZV10	GPRS/MMS/3G Samsung SGHZV10
Samsung	SGH-ZV30	GPRS/MMS/3G Samsung SGH-ZV30	GPRS/MMS/3G Samsung SGHZV30
Samsung	SGH-ZV40	GPRS/MMS/3G Samsung SGH-ZV40	GPRS/MMS/3G Samsung SGHZV40
Samsung	SGH-ZV50	GPRS/MMS/3G Samsung SGH-ZV50	GPRS/MMS/3G Samsung SGHZV50
Samsung	SGH-ZV60	GPRS/MMS/3G Samsung SGH-ZV60	GPRS/MMS/3G Samsung SGHZV60
Samsung	SGH-ZX10	GPRS/MMS/3G Samsung SGH-ZX10	GPRS/MMS/3G Samsung SGHZX10
Samsung	SGH-ZX20	GPRS/MMS/3G Samsung SGH-ZX20	GPRS/MMS/3G Samsung SGHZX20
Sendo	M570	GPRS/MMS/3G Sendo M570	GPRS/MMS/3G Sendo M-570
Sendo	P600	GPRS/MMS/3G Sendo P600	GPRS/MMS/3G Sendo P-600
Sendo	S330	GPRS/MMS/3G Sendo S330	GPRS/MMS/3G Sendo S-330
Sendo	S360	GPRS/MMS/3G Sendo S360	GPRS/MMS/3G Sendo S-360
Sendo	S600	GPRS/MMS/3G Sendo S600	GPRS/MMS/3G Sendo S-600
Sendo	SV663	GPRS/MMS/3G Sendo SV663	GPRS/MMS/3G Sendo SV-663
Sendo	X	GPRS/MMS/3G Sendo X	
Siemens	1168	GPRS/MMS/3G Siemens 1168	
Siemens	2118	GPRS/MMS/3G Siemens 2118	
Siemens	2128	GPRS/MMS/3G Siemens 2128	
Siemens	3118	GPRS/MMS/3G Siemens 3118	
Siemens	3508	GPRS/MMS/3G Siemens 3508	
Siemens	3508i	GPRS/MMS/3G Siemens 3508i	
Siemens	3518i	GPRS/MMS/3G Siemens 3518i	
Siemens	3568i	GPRS/MMS/3G Siemens 3568i	
Siemens	3618	GPRS/MMS/3G Siemens 3618	
Siemens	6618	GPRS/MMS/3G Siemens 6618	
Siemens	6686	GPRS/MMS/3G Siemens 6686	
Siemens	6686i	GPRS/MMS/3G Siemens 6686i	
Siemens	6688i	GPRS/MMS/3G Siemens 6688i	
Siemens	8008	GPRS/MMS/3G Siemens 8008	
Siemens	A31	GPRS/MMS/3G Siemens A31	GPRS/MMS/3G Siemens A-31

Siemens	A31a	GPRS/MMS/3G Siemens A31a	GPRS/MMS/3G Siemens A-31a
Siemens	A50	GPRS/MMS/3G Siemens A50	GPRS/MMS/3G Siemens A-50
Siemens	A51	GPRS/MMS/3G Siemens A51	GPRS/MMS/3G Siemens A-51
Siemens	A53	GPRS/MMS/3G Siemens A53	GPRS/MMS/3G Siemens A-53
Siemens	A55	GPRS/MMS/3G Siemens A55	GPRS/MMS/3G Siemens A-55
Siemens	A56	GPRS/MMS/3G Siemens A56	GPRS/MMS/3G Siemens A-56
Siemens	A56i	GPRS/MMS/3G Siemens A56i	GPRS/MMS/3G Siemens A-56i
Siemens	A57	GPRS/MMS/3G Siemens A57	GPRS/MMS/3G Siemens A-57
Siemens	A60	GPRS/MMS/3G Siemens A60	GPRS/MMS/3G Siemens A-60
Siemens	A62	GPRS/MMS/3G Siemens A62	GPRS/MMS/3G Siemens A-62
Siemens	A65	GPRS/MMS/3G Siemens A65	GPRS/MMS/3G Siemens A-65
Siemens	A75	GPRS/MMS/3G Siemens A75	GPRS/MMS/3G Siemens A-75
Siemens	A76	GPRS/MMS/3G Siemens A76	GPRS/MMS/3G Siemens A-76
Siemens	AF51	GPRS/MMS/3G Siemens AF51	GPRS/MMS/3G Siemens AF-51
Siemens	AL21	GPRS/MMS/3G Siemens AL21	GPRS/MMS/3G Siemens AL-21
Siemens	AL21a	GPRS/MMS/3G Siemens AL21a	GPRS/MMS/3G Siemens AL-21a
Siemens	AP75	GPRS/MMS/3G Siemens AP75	GPRS/MMS/3G Siemens AP-75
Siemens	AP75a	GPRS/MMS/3G Siemens AP75a	GPRS/MMS/3G Siemens AP-75a
Siemens	AX72	GPRS/MMS/3G Siemens AX72	GPRS/MMS/3G Siemens AX-72
Siemens	AX75	GPRS/MMS/3G Siemens AX75	GPRS/MMS/3G Siemens AX-75
Siemens	AX76	GPRS/MMS/3G Siemens AX76	GPRS/MMS/3G Siemens AX-76
Siemens	C35	GPRS/MMS/3G Siemens C35	GPRS/MMS/3G Siemens C-35
Siemens	C35i	GPRS/MMS/3G Siemens C35i	GPRS/MMS/3G Siemens C-35i
Siemens	C45	GPRS/MMS/3G Siemens C45	GPRS/MMS/3G Siemens C-45
Siemens	C53i	GPRS/MMS/3G Siemens C53i	GPRS/MMS/3G Siemens C-53i
Siemens	C55	GPRS/MMS/3G Siemens C55	GPRS/MMS/3G Siemens C-55
Siemens	C56	GPRS/MMS/3G Siemens C56	GPRS/MMS/3G Siemens C-56
Siemens	C60	GPRS/MMS/3G Siemens C60	GPRS/MMS/3G Siemens C-60
Siemens	C61	GPRS/MMS/3G Siemens C61	GPRS/MMS/3G Siemens C-61
Siemens	C62	GPRS/MMS/3G Siemens C62	GPRS/MMS/3G Siemens C-62
Siemens	C65	GPRS/MMS/3G Siemens C65	GPRS/MMS/3G Siemens C-65
Siemens	C65V	GPRS/MMS/3G Siemens C65V	GPRS/MMS/3G Siemens C-65V
Siemens	C66	GPRS/MMS/3G Siemens C66	GPRS/MMS/3G Siemens C-66
Siemens	C70	GPRS/MMS/3G Siemens C70	GPRS/MMS/3G Siemens C-70
Siemens	C71	GPRS/MMS/3G Siemens C71	GPRS/MMS/3G Siemens C-71
Siemens	C71a	GPRS/MMS/3G Siemens C71a	GPRS/MMS/3G Siemens C-71a
Siemens	C72	GPRS/MMS/3G Siemens C72	GPRS/MMS/3G Siemens C-72
Siemens	C75	GPRS/MMS/3G Siemens C75	GPRS/MMS/3G Siemens C-75
Siemens	C75V	GPRS/MMS/3G Siemens C75V	GPRS/MMS/3G Siemens C-75V
Siemens	CF110	GPRS/MMS/3G Siemens CF110	GPRS/MMS/3G Siemens CF-110
Siemens	CF61	GPRS/MMS/3G Siemens CF61	GPRS/MMS/3G Siemens CF-61
Siemens	CF61a	GPRS/MMS/3G Siemens CF61a	GPRS/MMS/3G Siemens CF-61a
Siemens	CF62	GPRS/MMS/3G Siemens CF62	GPRS/MMS/3G Siemens CF-62
Siemens	CF63	GPRS/MMS/3G Siemens CF63	GPRS/MMS/3G Siemens CF-63
Siemens	CF75	GPRS/MMS/3G Siemens CF75	GPRS/MMS/3G Siemens CF-75
Siemens	CF76	GPRS/MMS/3G Siemens CF76	GPRS/MMS/3G Siemens CF-76
Siemens	CFX65	GPRS/MMS/3G Siemens CFX65	GPRS/MMS/3G Siemens CFX-65
Siemens	CL50	GPRS/MMS/3G Siemens CL50	GPRS/MMS/3G Siemens CL-50
Siemens	CL75	GPRS/MMS/3G Siemens CL75	GPRS/MMS/3G Siemens CL-75
Siemens	CT56	GPRS/MMS/3G Siemens CT56	GPRS/MMS/3G Siemens CT-56
Siemens	CT65	GPRS/MMS/3G Siemens CT65	GPRS/MMS/3G Siemens CT-65
Siemens	CT70	GPRS/MMS/3G Siemens CT70	GPRS/MMS/3G Siemens CT-70
Siemens	CT71	GPRS/MMS/3G Siemens CT71	GPRS/MMS/3G Siemens CT-71
Siemens	CV65	GPRS/MMS/3G Siemens CV65	GPRS/MMS/3G Siemens CV-65
Siemens	CV70	GPRS/MMS/3G Siemens CV70	GPRS/MMS/3G Siemens CV-70

Siemens	CV71	GPRS/MMS/3G Siemens CV71	GPRS/MMS/3G Siemens CV-71
Siemens	CX65	GPRS/MMS/3G Siemens CX65	GPRS/MMS/3G Siemens CX-65
Siemens	CX70	GPRS/MMS/3G Siemens CX70	GPRS/MMS/3G Siemens CX-70
Siemens	CX70Emoty	GPRS/MMS/3G Siemens CX70Emoty	GPRS/MMS/3G Siemens CX70-Emoty
Siemens	CX75	GPRS/MMS/3G Siemens CX75	GPRS/MMS/3G Siemens CX-75
Siemens	CXi70	GPRS/MMS/3G Siemens CXi70	GPRS/MMS/3G Siemens CXi-70
Siemens	CXO65	GPRS/MMS/3G Siemens CXO65	GPRS/MMS/3G Siemens CXO-65
Siemens	CXT65	GPRS/MMS/3G Siemens CXT65	GPRS/MMS/3G Siemens CXT-65
Siemens	CXT70	GPRS/MMS/3G Siemens CXT70	GPRS/MMS/3G Siemens CXT-70
Siemens	CXV65	GPRS/MMS/3G Siemens CXV65	GPRS/MMS/3G Siemens CXV-65
Siemens	CXV70	GPRS/MMS/3G Siemens CXV70	GPRS/MMS/3G Siemens CXV-70
Siemens	M35	GPRS/MMS/3G Siemens M35	GPRS/MMS/3G Siemens M-35
Siemens	M35i	GPRS/MMS/3G Siemens M35i	GPRS/MMS/3G Siemens M-35i
Siemens	M46	GPRS/MMS/3G Siemens M46	GPRS/MMS/3G Siemens M-46
Siemens	M50	GPRS/MMS/3G Siemens M50	GPRS/MMS/3G Siemens M-50
Siemens	M55	GPRS/MMS/3G Siemens M55	GPRS/MMS/3G Siemens M-55
Siemens	M56	GPRS/MMS/3G Siemens M56	GPRS/MMS/3G Siemens M-56
Siemens	M65	GPRS/MMS/3G Siemens M65	GPRS/MMS/3G Siemens M-65
Siemens	M75	GPRS/MMS/3G Siemens M75	GPRS/MMS/3G Siemens M-75
Siemens	MC60	GPRS/MMS/3G Siemens MC60	GPRS/MMS/3G Siemens MC-60
Siemens	MCT62	GPRS/MMS/3G Siemens MCT62	GPRS/MMS/3G Siemens MCT-62
Siemens	ME45	GPRS/MMS/3G Siemens ME45	GPRS/MMS/3G Siemens ME-45
Siemens	ME75	GPRS/MMS/3G Siemens ME75	GPRS/MMS/3G Siemens ME-75
Siemens	MT50	GPRS/MMS/3G Siemens MT50	GPRS/MMS/3G Siemens MT-50
Siemens	S35i	GPRS/MMS/3G Siemens S35i	GPRS/MMS/3G Siemens S-35i
Siemens	S40	GPRS/MMS/3G Siemens S40	GPRS/MMS/3G Siemens S-40
Siemens	S42	GPRS/MMS/3G Siemens S42	GPRS/MMS/3G Siemens S-42
Siemens	S45	GPRS/MMS/3G Siemens S45	GPRS/MMS/3G Siemens S-45
Siemens	S45i	GPRS/MMS/3G Siemens S45i	GPRS/MMS/3G Siemens S-45i
Siemens	S46	GPRS/MMS/3G Siemens S46	GPRS/MMS/3G Siemens S-46
Siemens	S55	GPRS/MMS/3G Siemens S55	GPRS/MMS/3G Siemens S-55
Siemens	S56	GPRS/MMS/3G Siemens S56	GPRS/MMS/3G Siemens S-56
Siemens	S57	GPRS/MMS/3G Siemens S57	GPRS/MMS/3G Siemens S-57
Siemens	S65	GPRS/MMS/3G Siemens S65	GPRS/MMS/3G Siemens S-65
Siemens	S66	GPRS/MMS/3G Siemens S66	GPRS/MMS/3G Siemens S-66
Siemens	S75	GPRS/MMS/3G Siemens S75	GPRS/MMS/3G Siemens S-75
Siemens	SF65	GPRS/MMS/3G Siemens SF65	GPRS/MMS/3G Siemens SF-65
Siemens	SFG75	GPRS/MMS/3G Siemens SFG75	GPRS/MMS/3G Siemens SFG-75
Siemens	SG75	GPRS/MMS/3G Siemens SG75	GPRS/MMS/3G Siemens SG-75
Siemens	SK65	GPRS/MMS/3G Siemens SK65	GPRS/MMS/3G Siemens SK-65
Siemens	SL42	GPRS/MMS/3G Siemens SL42	GPRS/MMS/3G Siemens SL-42
Siemens	SL45	GPRS/MMS/3G Siemens SL45	GPRS/MMS/3G Siemens SL-45
Siemens	SL45i	GPRS/MMS/3G Siemens SL45i	GPRS/MMS/3G Siemens SL-45i
Siemens	SL55	GPRS/MMS/3G Siemens SL55	GPRS/MMS/3G Siemens SL-55
Siemens	SL56	GPRS/MMS/3G Siemens SL56	GPRS/MMS/3G Siemens SL-56
Siemens	SL65	GPRS/MMS/3G Siemens SL65	GPRS/MMS/3G Siemens SL-65
Siemens	SL75	GPRS/MMS/3G Siemens SL75	GPRS/MMS/3G Siemens SL-75
Siemens	SP65	GPRS/MMS/3G Siemens SP65	GPRS/MMS/3G Siemens SP-65
Siemens	ST55	GPRS/MMS/3G Siemens ST55	GPRS/MMS/3G Siemens ST-55
Siemens	ST60	GPRS/MMS/3G Siemens ST60	GPRS/MMS/3G Siemens ST-60
Siemens	SX1	GPRS/MMS/3G Siemens SX1	GPRS/MMS/3G Siemens SX-1
Siemens	SXG75	GPRS/MMS/3G Siemens SXG75	GPRS/MMS/3G Siemens SXG-75
Siemens	U10	GPRS/MMS/3G Siemens U10	GPRS/MMS/3G Siemens U-10
Siemens	U15	GPRS/MMS/3G Siemens U15	GPRS/MMS/3G Siemens U-15
SonyEricsson	D750i	GPRS/MMS/3G SonyEricsson D750i	

SonyEricsson	F500i	GPRS/MMS/3G SonyEricsson F500i	
SonyEricsson	J200c	GPRS/MMS/3G SonyEricsson J200c	
SonyEricsson	J200i	GPRS/MMS/3G SonyEricsson J200i	
SonyEricsson	J210c	GPRS/MMS/3G SonyEricsson J210c	
SonyEricsson	J210i	GPRS/MMS/3G SonyEricsson J210i	
SonyEricsson	J220i	GPRS/MMS/3G SonyEricsson J220i	
SonyEricsson	J220a	GPRS/MMS/3G SonyEricsson J220a	
SonyEricsson	J220c	GPRS/MMS/3G SonyEricsson J220c	
SonyEricsson	J230i	GPRS/MMS/3G SonyEricsson J230i	
SonyEricsson	J230a	GPRS/MMS/3G SonyEricsson J230a	
SonyEricsson	J230c	GPRS/MMS/3G SonyEricsson J230c	
SonyEricsson	J300a	GPRS/MMS/3G SonyEricsson J300a	
SonyEricsson	J300c	GPRS/MMS/3G SonyEricsson J300c	
SonyEricsson	J300i	GPRS/MMS/3G SonyEricsson J300i	
SonyEricsson	K200a	GPRS/MMS/3G SonyEricsson K200a	
SonyEricsson	K200c	GPRS/MMS/3G SonyEricsson K200c	
SonyEricsson	K200i	GPRS/MMS/3G SonyEricsson K200i	
SonyEricsson	K220c	GPRS/MMS/3G SonyEricsson K220c	
SonyEricsson	K220i	GPRS/MMS/3G SonyEricsson K220i	
SonyEricsson	K300a	GPRS/MMS/3G SonyEricsson K300a	
SonyEricsson	K300c	GPRS/MMS/3G SonyEricsson K300c	
SonyEricsson	K300i	GPRS/MMS/3G SonyEricsson K300i	
SonyEricsson	K310a	GPRS/MMS/3G SonyEricsson K310a	
SonyEricsson	K310c	GPRS/MMS/3G SonyEricsson K310c	
SonyEricsson	K310i	GPRS/MMS/3G SonyEricsson K310i	
SonyEricsson	K320i	GPRS/MMS/3G SonyEricsson K320i	
SonyEricsson	K500c	GPRS/MMS/3G SonyEricsson K500c	
SonyEricsson	K500i	GPRS/MMS/3G SonyEricsson K500i	
SonyEricsson	K506c	GPRS/MMS/3G SonyEricsson K506c	
SonyEricsson	K508c	GPRS/MMS/3G SonyEricsson K508c	
SonyEricsson	K508i	GPRS/MMS/3G SonyEricsson K508i	
SonyEricsson	K510a	GPRS/MMS/3G SonyEricsson K510a	
SonyEricsson	K510c	GPRS/MMS/3G SonyEricsson K510c	
SonyEricsson	K510i	GPRS/MMS/3G SonyEricsson K510i	
SonyEricsson	K530c	GPRS/MMS/3G SonyEricsson K530c	
SonyEricsson	K530i	GPRS/MMS/3G SonyEricsson K530i	
SonyEricsson	K550c	GPRS/MMS/3G SonyEricsson K550c	
SonyEricsson	K550i	GPRS/MMS/3G SonyEricsson K550i	
SonyEricsson	K600i	GPRS/MMS/3G SonyEricsson K600i	
SonyEricsson	K608i	GPRS/MMS/3G SonyEricsson K608i	
SonyEricsson	K610c	GPRS/MMS/3G SonyEricsson K610c	
SonyEricsson	K610i	GPRS/MMS/3G SonyEricsson K610i	
SonyEricsson	K618i	GPRS/MMS/3G SonyEricsson K618i	
SonyEricsson	K630i	GPRS/MMS/3G SonyEricsson K630i	
SonyEricsson	K700	GPRS/MMS/3G SonyEricsson K700	
SonyEricsson	K700c	GPRS/MMS/3G SonyEricsson K700c	
SonyEricsson	K700i	GPRS/MMS/3G SonyEricsson K700i	
SonyEricsson	K750i	GPRS/MMS/3G SonyEricsson K750i	
SonyEricsson	K750a	GPRS/MMS/3G SonyEricsson K750a	
SonyEricsson	K750c	GPRS/MMS/3G SonyEricsson K750c	
SonyEricsson	K770i	GPRS/MMS/3G SonyEricsson K770i	
SonyEricsson	K790a	GPRS/MMS/3G SonyEricsson K790a	
SonyEricsson	K790i	GPRS/MMS/3G SonyEricsson K790i	
SonyEricsson	K800c	GPRS/MMS/3G SonyEricsson K800c	
SonyEricsson	K800i	GPRS/MMS/3G SonyEricsson K800i	

SonyEricsson	K810i	GPRS/MMS/3G SonyEricsson K810i	
SonyEricsson	K818c	GPRS/MMS/3G SonyEricsson K818c	
SonyEricsson	K850a	GPRS/MMS/3G SonyEricsson K850a	
SonyEricsson	K850i	GPRS/MMS/3G SonyEricsson K850i	
SonyEricsson	K858c	GPRS/MMS/3G SonyEricsson K858c	
SonyEricsson	M608c	GPRS/MMS/3G SonyEricsson M608c	
SonyEricsson	M600i	GPRS/MMS/3G SonyEricsson M600i	
SonyEricsson	P1c	GPRS/MMS/3G SonyEricsson P1c	
SonyEricsson	P1i	GPRS/MMS/3G SonyEricsson P1i	
SonyEricsson	P800	GPRS/MMS/3G SonyEricsson P800	
SonyEricsson	P802	GPRS/MMS/3G SonyEricsson P802	
SonyEricsson	P900	GPRS/MMS/3G SonyEricsson P900	
SonyEricsson	P902	GPRS/MMS/3G SonyEricsson P902	
SonyEricsson	P908	GPRS/MMS/3G SonyEricsson P908	
SonyEricsson	P910a	GPRS/MMS/3G SonyEricsson P910a	
SonyEricsson	P910c	GPRS/MMS/3G SonyEricsson P910c	
SonyEricsson	P910i	GPRS/MMS/3G SonyEricsson P910i	
SonyEricsson	P990c	GPRS/MMS/3G SonyEricsson P990c	
SonyEricsson	P990i	GPRS/MMS/3G SonyEricsson P990i	
SonyEricsson	S500c	GPRS/MMS/3G SonyEricsson S500c	
SonyEricsson	S500i	GPRS/MMS/3G SonyEricsson S500i	
SonyEricsson	S700a	GPRS/MMS/3G SonyEricsson S700a	
SonyEricsson	S700c	GPRS/MMS/3G SonyEricsson S700c	
SonyEricsson	S700i	GPRS/MMS/3G SonyEricsson S700i	
SonyEricsson	S710a	GPRS/MMS/3G SonyEricsson S710a	
SonyEricsson	T100	GPRS/MMS/3G SonyEricsson T100	
SonyEricsson	T102	GPRS/MMS/3G SonyEricsson T102	
SonyEricsson	T105	GPRS/MMS/3G SonyEricsson T105	
SonyEricsson	T106	GPRS/MMS/3G SonyEricsson T106	
SonyEricsson	T200	GPRS/MMS/3G SonyEricsson T200	
SonyEricsson	T202	GPRS/MMS/3G SonyEricsson T202	
SonyEricsson	T226	GPRS/MMS/3G SonyEricsson T226	
SonyEricsson	T226m	GPRS/MMS/3G SonyEricsson T226m	
SonyEricsson	T226s	GPRS/MMS/3G SonyEricsson T226s	
SonyEricsson	T230	GPRS/MMS/3G SonyEricsson T230	
SonyEricsson	T237	GPRS/MMS/3G SonyEricsson T237	
SonyEricsson	T237s	GPRS/MMS/3G SonyEricsson T237s	
SonyEricsson	T238	GPRS/MMS/3G SonyEricsson T238	
SonyEricsson	T250a	GPRS/MMS/3G SonyEricsson T250a	
SonyEricsson	T250i	GPRS/MMS/3G SonyEricsson T250i	
SonyEricsson	T258c	GPRS/MMS/3G SonyEricsson T258c	
SonyEricsson	T290a	GPRS/MMS/3G SonyEricsson T290a	
SonyEricsson	T290c	GPRS/MMS/3G SonyEricsson T290c	
SonyEricsson	T290i	GPRS/MMS/3G SonyEricsson T290i	
SonyEricsson	T292a	GPRS/MMS/3G SonyEricsson T292a	
SonyEricsson	T300	GPRS/MMS/3G SonyEricsson T300	
SonyEricsson	T302	GPRS/MMS/3G SonyEricsson T302	
SonyEricsson	T306	GPRS/MMS/3G SonyEricsson T306	
SonyEricsson	T310	GPRS/MMS/3G SonyEricsson T310	
SonyEricsson	T312	GPRS/MMS/3G SonyEricsson T312	
SonyEricsson	T316	GPRS/MMS/3G SonyEricsson T316	
SonyEricsson	T600	GPRS/MMS/3G SonyEricsson T600	
SonyEricsson	T602	GPRS/MMS/3G SonyEricsson T602	
SonyEricsson	T610	GPRS/MMS/3G SonyEricsson T610	
SonyEricsson	T616	GPRS/MMS/3G SonyEricsson T616	

SonyEricsson	T618	GPRS/MMS/3G SonyEricsson T618	
SonyEricsson	T61z	GPRS/MMS/3G SonyEricsson T61z	
SonyEricsson	T628	GPRS/MMS/3G SonyEricsson T628	
SonyEricsson	T62u	GPRS/MMS/3G SonyEricsson T62u	
SonyEricsson	T630	GPRS/MMS/3G SonyEricsson T630	
SonyEricsson	T637	GPRS/MMS/3G SonyEricsson T637	
SonyEricsson	T650i	GPRS/MMS/3G SonyEricsson T650i	
SonyEricsson	T658c	GPRS/MMS/3G SonyEricsson T658c	
SonyEricsson	T68i	GPRS/MMS/3G SonyEricsson T68i	
SonyEricsson	V600i	GPRS/MMS/3G SonyEricsson V600i	
SonyEricsson	V630i	GPRS/MMS/3G SonyEricsson V630i	
SonyEricsson	V640i	GPRS/MMS/3G SonyEricsson V640i	
SonyEricsson	Vodafone 802SE	GPRS/MMS/3G SE Vodafone802SE	GPRS/MMS/3G SE Vodafone-802SE
SonyEricsson	W200a	GPRS/MMS/3G SonyEricsson W200a	
SonyEricsson	W200c	GPRS/MMS/3G SonyEricsson W200c	
SonyEricsson	W200i	GPRS/MMS/3G SonyEricsson W200i	
SonyEricsson	W300i	GPRS/MMS/3G SonyEricsson W300i	
SonyEricsson	W550c	GPRS/MMS/3G SonyEricsson W550c	
SonyEricsson	W550i	GPRS/MMS/3G SonyEricsson W550i	
SonyEricsson	W580i	GPRS/MMS/3G SonyEricsson W580i	
SonyEricsson	W580c	GPRS/MMS/3G SonyEricsson W580c	
SonyEricsson	W600a	GPRS/MMS/3G SonyEricsson W600a	
SonyEricsson	W600i	GPRS/MMS/3G SonyEricsson W600i	
SonyEricsson	W610c	GPRS/MMS/3G SonyEricsson W610c	
SonyEricsson	W610i	GPRS/MMS/3G SonyEricsson W610i	
SonyEricsson	W660i	GPRS/MMS/3G SonyEricsson W660i	
SonyEricsson	W700c	GPRS/MMS/3G SonyEricsson W700c	
SonyEricsson	W700i	GPRS/MMS/3G SonyEricsson W700i	
SonyEricsson	W710c	GPRS/MMS/3G SonyEricsson W710c	
SonyEricsson	W710i	GPRS/MMS/3G SonyEricsson W710i	
SonyEricsson	W800i	GPRS/MMS/3G SonyEricsson W800i	
SonyEricsson	W800c	GPRS/MMS/3G SonyEricsson W800c	
SonyEricsson	W810c	GPRS/MMS/3G SonyEricsson W810c	
SonyEricsson	W810i	GPRS/MMS/3G SonyEricsson W810i	
SonyEricsson	W830c	GPRS/MMS/3G SonyEricsson W830c	
SonyEricsson	W830i	GPRS/MMS/3G SonyEricsson W830i	
SonyEricsson	W850i	GPRS/MMS/3G SonyEricsson W850i	
SonyEricsson	W880i	GPRS/MMS/3G SonyEricsson W880i	
SonyEricsson	W888c	GPRS/MMS/3G SonyEricsson W888c	
SonyEricsson	W890i	GPRS/MMS/3G SonyEricsson W890i	
SonyEricsson	W900c	GPRS/MMS/3G SonyEricsson W900c	
SonyEricsson	W900i	GPRS/MMS/3G SonyEricsson W900i	
SonyEricsson	W908c	GPRS/MMS/3G SonyEricsson W908c	
SonyEricsson	W910i	GPRS/MMS/3G SonyEricsson W910i	
SonyEricsson	W950i	GPRS/MMS/3G SonyEricsson W950i	
SonyEricsson	W958c	GPRS/MMS/3G SonyEricsson W958c	
SonyEricsson	W960i	GPRS/MMS/3G SonyEricsson W960i	
SonyEricsson	Z1010	GPRS/MMS/3G SonyEricsson Z1010	
SonyEricsson	Z200	GPRS/MMS/3G SonyEricsson Z200	
SonyEricsson	Z208	GPRS/MMS/3G SonyEricsson Z208	
SonyEricsson	Z250a	GPRS/MMS/3G SonyEricsson Z250a	
SonyEricsson	Z250i	GPRS/MMS/3G SonyEricsson Z250i	
SonyEricsson	Z258c	GPRS/MMS/3G SonyEricsson Z258c	
SonyEricsson	Z300a	GPRS/MMS/3G SonyEricsson Z300a	
SonyEricsson	Z300c	GPRS/MMS/3G SonyEricsson Z300c	

SonyEricsson	Z300i	GPRS/MMS/3G SonyEricsson Z300i	
SonyEricsson	Z310a	GPRS/MMS/3G SonyEricsson Z310a	
SonyEricsson	Z310c	GPRS/MMS/3G SonyEricsson Z310c	
SonyEricsson	Z310i	GPRS/MMS/3G SonyEricsson Z310i	
SonyEricsson	Z320a	GPRS/MMS/3G SonyEricsson Z320a	
SonyEricsson	Z320i	GPRS/MMS/3G SonyEricsson Z320i	
SonyEricsson	Z500a	GPRS/MMS/3G SonyEricsson Z500a	
SonyEricsson	Z500c	GPRS/MMS/3G SonyEricsson Z500c	
SonyEricsson	Z500i	GPRS/MMS/3G SonyEricsson Z500i	
SonyEricsson	Z502a	GPRS/MMS/3G SonyEricsson Z502a	
SonyEricsson	Z520a	GPRS/MMS/3G SonyEricsson Z520a	
SonyEricsson	Z520c	GPRS/MMS/3G SonyEricsson Z520c	
SonyEricsson	Z520i	GPRS/MMS/3G SonyEricsson Z520i	
SonyEricsson	Z525a	GPRS/MMS/3G SonyEricsson Z525a	
SonyEricsson	Z525i	GPRS/MMS/3G SonyEricsson Z525i	
SonyEricsson	Z530c	GPRS/MMS/3G SonyEricsson Z530c	
SonyEricsson	Z530i	GPRS/MMS/3G SonyEricsson Z530i	
SonyEricsson	Z550a	GPRS/MMS/3G SonyEricsson Z550a	
SonyEricsson	Z550c	GPRS/MMS/3G SonyEricsson Z550c	
SonyEricsson	Z550i	GPRS/MMS/3G SonyEricsson Z550i	
SonyEricsson	Z558i	GPRS/MMS/3G SonyEricsson Z558i	
SonyEricsson	Z600	GPRS/MMS/3G SonyEricsson Z600	
SonyEricsson	Z608	GPRS/MMS/3G SonyEricsson Z608	
SonyEricsson	Z610i	GPRS/MMS/3G SonyEricsson Z610i	
SonyEricsson	Z710c	GPRS/MMS/3G SonyEricsson Z710c	
SonyEricsson	Z710i	GPRS/MMS/3G SonyEricsson Z710i	
SonyEricsson	Z750i	GPRS/MMS/3G SonyEricsson Z750i	
SonyEricsson	Z750a	GPRS/MMS/3G SonyEricsson Z750a	
SonyEricsson	Z800i	GPRS/MMS/3G SonyEricsson Z800i	
UTStarcom	GPRS748	GPRS/MMS/3G UTStarcom GPRS748	GPRS/MMS/3G UTStarcom GPRS-748
UTStarcom	GPRS749	GPRS/MMS/3G UTStarcom GPRS749	GPRS/MMS/3G UTStarcom GPRS-749
UTStarcom	GPRS758	GPRS/MMS/3G UTStarcom GPRS758	GPRS/MMS/3G UTStarcom GPRS-758
Vertu	Ascent RHV-3	GPRS/MMS/3G Vertu AscentRHV-3	GPRS/MMS/3G Vertu Ascent-RHV-3
Vertu	Ascent RHV-5	GPRS/MMS/3G Vertu AscentRHV-5	GPRS/MMS/3G Vertu Ascent-RHV-5
Vertu	Signature RHV-2	GPRS/MMS/3G Vertu SignatureRHV-2	GPRS/MMS/3G Vertu Signature-RHV-2
verykool	i200	GPRS/MMS/3G verykool i200	GPRS/MMS/3G verykool i-200
verykool	i500	GPRS/MMS/3G verykool i500	GPRS/MMS/3G verykool i-500
VKMobile	VK2000	GPRS/MMS/3G VKMobile VK2000	GPRS/MMS/3G VKMobile VK-2000
VKMobile	VK2020	GPRS/MMS/3G VKMobile VK2020	GPRS/MMS/3G VKMobile VK-2020